


# The friendly magmeter

# OPERATING AND MAINTENANCE MANUAL



**MV255** 

CE



Release number: MAN\_MV255\_IT\_EN\_IS\_R16\_1.06.XXXX

The characters of file name in bold type indicate the software version which the manual refers to; it is visualized at the instrument start up, or by specific function on DIAGNOSTIC menu.

The reproduction of this manual and any supplied software is strictly forbidden.





### INDEX:

INTRODUCTION	4
SAFETY INFORMATION	4
SAFETY CONVENTION	5
FIRST POWER-UP OF THE INSTRUMENT FOLLOWING COMMISSIONING	6
SWITCHING OFF THE INSTRUMENT	6
CONDITIONS DELIVERY OF THE CONVERTER	7
SIM-CARD INSTALLATION	7
TECHNICAL CHARACTERISTICS	8
OVERALL DIMENSIONS WITHOUT BATTERY CASE	10
OVERALL DIMENSIONS WITH BATTERY CASE	13
TORQUES	16
CASE WEIGHT CONVERTER AND BATTERIES	16
MV255 CONSTRUCTION	17
INTERNAL LAYOUT	19
POWER SUPPLY CONVERTER	20
POWER SUPPLY BATTERIES	21
ESTIMATED CONSUMPTION OF LITHIUM BATTERIES	23
EXTERNAL POWER SUPPLY	25
POWER SUPPLY FROM MAIN LINE	26
ELECTRICAL CONNECTION CONVERTER- SENSOR	28
INPUT CONNECTIONS	29
OUTPUTS CONNECTIONS	33
USCITA 4-20MA	34
MIL CONNECTOR	36
START VISUALIZATION PAGES	39
ACCESS TO THE CONVERTER	42
ACCESS TO THE CONFIGURATION MENU	44
FLOW RATE VISUALIZATION	45

# ISOMAG.

QUICK START MENU	46
CONVERTER ACCESS CODE	47
FUNCTIONS MENU	50
FUNCTIONS DESCRIPTION	56
MENU 1 - SENSOR	57
MENU 2 - UNITS	60
MENU 3 SCALE	62
MENU 4 MEASURE	63
MENU 5 ALARMS	65
MENU 6 INPUTS	67
MENU 7 OUTPUTS	68
MENU 8 COMMUNICATION	71
MENU 9 DISPLAY	80
MENU 10 DATA LOGGER	81
DATA MANAGEMENT MEASURES AND EVENTS	83
USING DATA LOGGER BY MCP INTERFACE	84
MENU 11 - FUNCTION	91
MENU 12 - DIAGNOSTIC	92
MENU 13 - SYSTEM	96
MENU 14 - FILE (ONLY MCP)	102
MENU 15 - PROCESS DATA (ONLY MCP)	103
METER DATA	106
B.I.V. (BUILT-IN VERIFICATOR)	108
MCS SOFTWARE	112
ALARM MESSAGES (CAUSES AND ACTIONS TO BE TAKEN)	113
ERROR CODE TEST SYSTEM OF SENSOR	116



MANUAL REVIEWS




119



### INTRODUCTION

- These operating instructions and description of device functions are provided as part of the scope of supply.
- ☐ They could be modified without prior notice. The improper use, possible tampering of the instrument or parts of it and substitutions of any components not original, renders the warranty automatically void.
- The flow meter realizes a measure with liquids of conductivity greater than 5µS/cm in closed conduits, and is composed of a converter (described in this manual) and a sensor (refer to the specific manual).
- The converter could be coupled directly on the sensor (compact version) or coupled to the sensor by cable supplied with it (remote version).



### **SAFETY INFORMATION**

Any use other than described in this manual affects the protection provided by the manufacturer and compromises the safety of people and the entire measuring system and is, therefore, not permitted. The manufacturer is not liable for damaged caused by improper or non-designated use.

- ☐ Transport the measuring device to the measuring point in the original packaging. Do not remove covers or caps until immediately before installation. In case of cartons packaging it is possible to place one above the other but no more than three cartons. In case of wooden packaging do not place one above the other.
- ☐ Disposal of this product or parts of it must be carried out according to the local public or private waste collection service regulations.
- ☐ The converter must only be installed, connected and maintained by qualified and authorized specialists (e.g. electrical technicians) in full compliance with the instructions in this Operating Instruction, the applicable norms, legal regulations and certificates (depending on the application).
- ☐ The specialists must have read and understood these Operating Instructions and must follow the instructions it contains. The Operating Instructions provide detailed information about the converter. If you are unclear on anything in these Operating Instructions, you must call the ISOIL service department.



The converter should only be installed after have verified technical data provided in these operating instructions and on the data plate.
Specialists must take care during installation and use personal protective equipment as provided by any related security plan or risk assessment.
Never mount or wire the converter while it is connected to the power supply and avoid any liquid contact with the
The converter housing integrity
The suitable tightness of the sealing elements
The front panel integrity (display and keyboard)
The mechanical fixing of the converter to the pipe or wall standinstrument's internal components. To connect remove the terminals from the terminal block.
Before connecting the power supply check the functionality of the safety equipment.
Repairs may only be performed if a genuine spare parts kit is available and this repair work is expressly permitted.
For the cleaning of the device use only a damp cloth, and for the maintenance/repairs contact the service center (for details see the last page).
Before starting up the equipment please verify the following:
Power supply voltage must correspond to that specified on the data plate
Electric connections must be completed as described
Ground (earth) connections must be completed as specified
The power supply cables integrity, wiring and other connected electrical parts
Verify periodically (every 3-4 months):

### **SAFETY CONVENTION**



DANGER ELETTRIC SHOCK



WARNING



**PRECAUTIONS** 



**ATTENTION** 





### FIRST POWER-UP OF THE INSTRUMENT FOLLOWING COMMISSIONING

Follow the procedure below:

Connect the USB port of the instrument to a PC or other equivalent device capable of delivering at least 500 mA
from the USB interface;

- ☐ Make sure that both status LEDs on the instrument are flashing;
- Use the MCP interface to send a hardware reset command; and
- ☐ Wait for operation to resume and for all current operations on the modem to complete
- ☐ Send the "ATSIC" command and verify that the instrument has restarted correctly



Follow this procedure also whenever battery power is completely disconnected.

### SWITCHING OFF THE INSTRUMENT

Follow the procedure below:


- ☐ Connect a PC or other equivalent device to the USB port and start the MCP interface.
- Disconnect any external power supply.
- □ Send the command "SSTBY" and wait for all the current operations on the modem to complete (it may take up to 2 minutes). A message appears on the MCP interface display indicating that the USB cable can be disconnected. If the cable is not disconnected, the instrument will NOT enter standby mode and both status LEDs will then remain lighted. If there are modem operations in progress, the status LED of the communication CPU will be flashing and will turn steady red only when all operations are completed.
- Once the USB cable is disconnected, make sure BOTH LEDs turn off and remain off.
- Disconnect the batteries from the device



### **CONDITIONS DELIVERY OF THE CONVERTER**



**WARNING!** The converter is supplied with the batteries disconnected so it is necessary to remove the terminal block cover, as shown below, and connect them according to the indications given in the section "power supply converter" pag. 20




Programming is allowed in two ways:

- ☐ Connecting a power bank ≥0.5 Ah to the USB jack. (Programming from converter keyboard)
- □ Connecting a computer to the USB socket using the MCP program see section "Access via mcp interface (virtual display)" pag. 45.

### SIM-CARD INSTALLATION



**WARNING!** The SIM-CARD must be inserted in the device with the instrument not powered. For the position of the SIM-CARD slot see section "Internal layout" pag. 19.





7 di 122



### TECHNICAL CHARACTERISTICS

### **Electrical Characteristic**

Converter classification: class I,

IP67 (where: 6 = totally protected against dust, 7 = Protected against the effects of temporary immersion)

IP68 (where: 6 = totally protected against dust, 8 = continuous immersion 1.5 m; 1 h)

for aluminum and PA6 housing, installation category (overvoltage) II, rated pollution degree 2.

Power supply version	Power supply voltage	Power supply frequency	Min Power	Max Power
HV	100-240V~	45-66HZ	1.5 W	4w
LLV	12-48V	//	(Sensor only)	(all loads)
Lithium Battery Primary	7,2 V	//	40 mW	200 mW
Alkaline Battery 6 Size D x 15v	9V	//	40 mW	200 mW

■ Voltage variations must not exceed ±10% of the nominal one.

Digital and analogue inputs and outputs are isolated up to 500V.

 $\Box$  The output 4-20mA (optional) is electrically connected to the ON/OFF outputs and the output power supply(24V === ).

☐ Version LV/LLV : inrush current < 20A

☐ Version HV : inrush current< 25A

**NOTE:** The system, if powered with HV / LLV voltage, requires the use of a rechargeable lithium battery and cannot function if it is disconnected from the system. This condition also applies if the system is connected with a USB socket.

### **Environmental Use Conditions**

ALLUMI	NYLO	N PA6			
TEMPERATURE	Min*	Max	TEMPERATURE	Min*	Max
°C	-20	+60	°C	-10	+50
°F	-4	+140	°F	+14	+122

If the converter is supplied in compact version, consider the most restrictive ambient temperatures between converter and sensor, otherwise refer to the respective manuals.\* For discontinuous use install a heating resistor.



☐ The instrument is suitable for indoor and outdoor weather conditions

Altitude: from –200m to 4000m

☐ Humidity range: 0-100%

ATTENTION: Temperature limits beyond which the battery is not recharged

☐ T Board MV255 < 0 °C

☐ Tboard MV255 > 50 °C

### **Measurements Tolerance**

 $\Box$  Flow rate (volume) = ±0,1% o.r.

 $\Box$  Out 4/20 mA = ± 0,2 % o.r.

☐ Frequency Out = ± 0,2% o.r



### **Data Plate**

The instrument label contain the following information:

■ MODEL: Convert Model

☐ S/N: Serial Number of the converter

☐ SUPPLY: Main power supply

☐ Hz: Supply frequency (AC)


□ POWER: Maximum power consumption

☐ IP: Protection grade

☐ T: Operation temperature

□ COUPLING: Serial number of sensor coupled


☐ ITEM: Free for user










### **OVERALL DIMENSIONS WITHOUT BATTERY CASE**












## ISOMAG:


### **Compact version**





### **Compact version (rotated)**












### Separate version





# ISOMAG.

### **OVERALL DIMENSIONS WITH BATTERY CASE**










# The manufacturer guarantees only English text available on our web site www.isoil.com


### **Compact version**






### Compact version (rotated)









### Separate version





### Mil connector version

For details of connections with MIL connectors, refer to the manual: MV145-255\_MIL CONNECTOR POSITION.






### **TORQUES**


To guarantee the housing's IP degree the following torques are required:

MATERIAL HOUSING	Housing screw (1)	Cover terminal block screw (2)	Fixing Display Frame	PCB Screw	Version Cap(3)	Cable Glands (4)	Cap USB-B (5)
ALUMINIUM HOUSING	6 Nm	5.5 Nm	3 Nm	0.8 Nm	8 Nm	4 Nm	4 Nm
PLASTIC HOUSING	2 Nm	2 Nm	2.5 Nm	0.8 Nm	7 Nm	4 Nm	4 Nm
BATTERY HOUSING	2 Nm	//	//	//	//	//	//

### **Housing converter**



### **Battery case cover**




### **CASE WEIGHT CONVERTER AND BATTERIES**

	WEIGHT CONVERTER	BATTERY WEIGHT LITHIUM	BATTERY WEIGHT ALKALINE
PLASTIC HOUSING	2kg	EACH LITHIUM BATTERY WEIGHS 0.1kg;	EACH ALKALINE BATTERY WEIGHS 0.15 kg
ALUMINIUM HOUSING	3kg	EXPECTED MAXIMUM 6 BATTERIES	EXPECTED MAXIMUM 6 BATTERIES




### **MV255 CONSTRUCTION**


### **TERMINAL BLOCK COVER**




### **MAIN HOUSING COVER**



### **PCB MV255**



### **MAIN HOUSING**




	DESCRIPTION						
POS.	ΔΙΙΙΜΙΝΙΙΙΜ						
1 00.	PA6 VERSION	VERSION					
1	SCREW M4x12	SCREW M5x12					
2	GROWER Ø4	GROWER Ø5					
3	TERMINAL BLOCK COVER	TERMINAL BLOCK COVER					
4	O-RING	G-4400					
5	SELF-TAPPING SCREW 4x10	SELF-TAPPING SCREW 4x10					
6	PROTECTION	ON COVER					
7	HOUSING COVER	HOUSING COVER					
8	ORING	G-4700					
9	ORING	-117x3					
10	DISP	LAY					
11	FLAT C	CABLE					
12	FIXING DISPLAY FRAI	ME (MATERIAL PA06)					
	TERMINA SOLID WIRE: 26-16 A						
13	-16 AWG / 0.129-1.31						
	mm² TOPOLIE: 3.0.1 b.ln / 0.34 Nm						
14	TORQUE: 3.0 Lb.ln / 0.34 Nm PCB						
15	LITHIUM BATTERY						
16	PA6 MAIN HOUSING	ALUMINIUM MAIN HOUSING					
17	3G/4G AN						
	3G/4G ANTENNA WITH 3m CABLE						
18	LOCKING NUT						
19	WASH	ER Ø6					
20	O-RING 20	18 VITON					
21	O-RING-155						
22	VERSION CAP (MATERIAL PA06)						
23	ANTENNA CABLE 15cm						
24	PG9	CAP					
25	PRESSURE COMP						
26	PG11 CABL CABLE DIAMET						
27	GROW						
28	SCREW	M6x16					
	l						





### **BATTERY HOUSING**




	DES	CRIPTION				
POS.	PA6 VERSION	ALUMINIUM VERSION				
29	CAP BATTE	RY HOUSING PA6				
30	LITHIUM OR	ALKALINE BATTERY				
31	SUPPORT CONTACTS ALKALINE BATTERIES MV					
32	BATTERY HOUSING PA6					
33	SCREW M4X12					
34	O-RING 3050					
35	SEAL BUSH					
36	O-RING 3081					
37	O-F	RING 4575				



### **INTERNAL LAYOUT**

### **Internal Converter Views**

The 4 screws shown in the following figure can be removed if the battery case is disassembled first.









### **POWER SUPPLY CONVERTER**

MV255 can be powered in different modes

- ☐ Powered by lithium batteries in slots B1 / B2
- ☐ Power supply from alkaline batteries slot B3
- Power supply from the mains

Below are the positions of the terminal blocks for the different types of power supply.





### General notes for converter power supplies

- ☐ The converter can have different power combinations. However, all versions are able to operate at 100% of the possibilities even with only the power coming from the USB cable, transmission included. However, note that these devices are seen by the USB controller that supplies the energy as a 500 mA class device, so not all devices are able to power these electronics correctly (for example tablets and cell phones unless they are rare).
- □ With the USB connection there is no battery consumption, however it is necessary that all the batteries are connected to ensure operation and connection to the MCP software.
   NOTE: if the rechargeable battery is connected to B3, it is recharged by the USB connection.




### **POWER SUPPLY BATTERIES**

When the B1 and B2 batteries are connected for the first time or after a long period of inactivity of the instrument, the super-capacitors coupled to the batteries are completely discharged, therefore for a certain period of time the indications will be "B1 LOW" and "B2 LOW "Until the nominal voltage of the batteries is reached. The time required depends on many factors (temperature, passivation status of the batteries, amount of battery charge remaining). The estimated time for this transition state is less than an hour.


Primary lithium batteries

For primary lithium batteries, connections to slots B1, B2 (see "power supply converter" pag. 20) are prepared as follows:

In the slots B1 and B2 the installable batteries are:



The maximum number of battery elements housed in the battery holder is 6.








### **Alkaline batteries**

The alkaline batteries foreseen for the MV255 converter are 6 Size D elements. The alkaline battery pack is connected in the B3 slot of the converter ("power supply converter" pag. 20)





### Operating notes

- ☐ Always replace all batteries at the same time as indicated on the battery holder.
- ☐ Do not mix new and used batteries or batteries with different characteristics.
- ☐ To maintain valid time and date when replacing batteries, connect the unit with a USB power source capable of supplying at least 500 mA.



N.B: With fully discharged batteries, the instrument may operate abnormally because the internal voltages would not be stable, so operating the instrument in this state is to be avoided.




### **ESTIMATED CONSUMPTION OF LITHIUM BATTERIES**

The consumption of lithium batteries depends mainly on:

- Sensor diameter.
- Data logger sampling interval.
- Number of connections to external loggers (4-20 mA or via MODBUS).
- Measurement profile (CONTINUOUS, ENERGY SAVING MODE).

Note: for other configurations / type of batteries separate consumption cannot be estimated.



For further details concerning the sampling interval and the management of the measurement power profiles see function POS "4.1" pag. 51







The average	life of the I	oatteries as	far as the	measuremen	t part is	concerned	can be	estimated	in the s	tandard	conditions
of use.											


Consumption regarding the data transmission part depends on:

- ☐ The interval for sending data.
- Amount of data to send.
- ☐ Transmission conditions (connection protocol, type of radio link, distance from the receiving station)

It is possible to estimate the useful life of the batteries for the transmission part only within certain limits. In any case, the forecasts depend very much on the quality of the batteries.



### **EXTERNAL POWER SUPPLY**



### Notes about MV255 external power supply

☐ When NON-rechargeable batteries are provided and equipped with an external power supply module, they CANNOT be powered directly by solar panel because this type of power supply is not constant and in low light can result in very high battery consumption. Therefore, for proper operation of the instruments, it is necessary for the external power supply to be able to provide constant power of at least 2 W. The minimum voltage under maximum load condition should NOT be less than 9V. The transition from a valid power supply state to one where the voltage/power can no longer support the consumption of the electronics is not sharp but being an analog value, it can remain in an ambiguous boundary condition. In addition, since the only input data for the electronics is the voltage, it happens that if the panel is dimly lit, the voltage AT VACUUM or in a condition of very low consumption of the electronics may also be sufficient, but as soon as the instrument passes into the active condition, the increased consumption causes the input voltage to drop immediately, causing the instrument to return to the low consumption mode. This causes the voltage to rise again, and the cycle repeats indefinitely if the conditions persist. In addition, the continuous state change could continuously activate and then deactivate the modem (if SMS control is active, for example), causing even higher consumption, since it takes on average about 20 seconds per phase to engage and then disengage the network. During this time, consumption is very high because the modem is transmitting synchronization data to the network and the whole thing would then rely on the instrument's battery. For the above reasons, it is necessary for the solar panel to feed a system with built-in voltage and power output regulation. Typically these systems include a battery and a regulator, so that the output voltage is stable and with well-defined cut-off in case of insufficient primary power.






### POWER SUPPLY FROM MAIN LINE



Always ensure that the converter and the sensor are grounded (earthed) correctly. The grounding of the sensor and converter must ensure that the instrument and liquid are equipotential.



- Before connecting the power supply, verify that the mains voltage is within the limits indicated on data plate. The mains-powered converter is not supplied with the battery holder.
- ☐ For the connections use only approved conductors, with fire-proof properties, whose section varies from 0.25mm2 to 1.50mm2, based on distance/power; additionally fix the power supply wires with a additional fastening system located close to the terminal.
- The power supply line must be equipped with an external protection for overload current (fuse or automatic line breaker).
- Provide in close proximity the converter a circuit breaker easily accessible for the operator and clearly identified; whose symbols must conform to the electrical safety and local electrical requirements.
- ☐ Ensure that the component complies with the requirements of the standard for electrical safety distance.
- ☐ Check chemical compatibility of materials used in the connection security systems in order to minimize electrochemical corrosion. In the aluminum housing it should avoid direct contact between the ground connection cable and the aluminum housing. It is therefore recommended to connect the safety ground cable, by placing it between the washer and the metal bracket on the related terminal or use an eyelet terminal crimped on the ground protection cable.
- ☐ The sensor, hard wired inputs and outputs are connected to the converter through terminal blocks located inside the converter.
- □ To locate the terminal block loosen the 4 screws on the terminal block cover. When the front cover is lifted, the terminal block is visible. The terminal block is the hard wire connection of the converter to external equipment, including the sensor.
- ☐ A rechargeable lithium battery connected to slot B3 is provided inside the converter powered by the mains power supply (see "power supply converter" pag. 20).



### **SLOT (B3) RECHARGEABLE LITHIUM**





### Operating notes for mains power supply

- ☐ The system cannot work with the battery disconnected or completely discharged, even if it is powered by an external power source (network or USB).
- □ 3G/4G communication cannot work if the B3 battery is disconnected, even if the USB power supply is present.
- ☐ With the USB cable connected there is no battery consumption, however it is necessary that B3 is connected to ensure operation.

The following pages give informations on the terminal block numbering, and the respective connecting of the sensor cables, and inputs/outputs.






### **ELECTRICAL CONNECTION CONVERTER- SENSOR**

### Terminal block converter



Sudden movements of the electrodes cable could introduce noise. Maximum cable length: 20m.






### **INPUT CONNECTIONS**

### Digital input connections on a base card (INP COM, INP II, INP V+)


The digital input can be used in two ways as shown below:

- ☐ IN 1: input 1, positive terminal
- INC: common of all inputs
- ☐ INPWR: isolated voltage generator output for inputs power supply

### Internal power supply



### **External Power Supply**







### input on / off mode for operating inputs

In energy saving mode, the activation times of the Tmin input must be ≥15 seconds. For electrical connections see "ELECTRICAL CONNECTION CONVERTER- SENSOR" pag. 28.

SCHEMES	CONDITIONS REQUIRED TO PERFORM THE FUNCTION
Block 3-40V Reset  T Tmin	TOTALIZER RESET (Input 1): enable all or only the functions related to the totalizer to be reset.  "6.1" pag. 52  "6.2" pag. 52  "6.3" pag. 52  "6.4" pag. 52  CALIBRATION (Input 1): T> 0.5 seconds  "6.7" pag. 52
3-40V Totalizers Active	TOTALIZER LOCK (Input 1): enable the function if the counting of the totalizers is to be blocked. "6.5" pag. 52
18-30V Measure blocked	MEASUREMENT BLOCK (Input 1): enable the function if desired flow measurement block.  "6.6" pag. 52
Alarm not activated  3-40V  Alarm activated	SYSTEM VIOLATION (Input 1): enable the function if you want to activate the system violation alarm. This function disables the previous functions "6.8" pag. 52
Alarm not activated  3-40V  Alarm activated	SYSTEM / FLOOD VIOLATION (Input 2 and / or 3 if enabled): enable the function if you want to activate the system violation and / or flood alarm. "6.9" pag. 52 "6.10" pag. 52




### Analog input connections (Al1+, Al1-, Al2+, Al2-, Al3+, COM)

- ☐ AIN1 +, AIN1-: inputs (+) and (-) for acquisition of analogue channel 1 measurements
- ☐ AIN2 +, AIN 2-: inputs (+) and (-) for acquisition of analogue channel 2 measurements
- AIN PWR +: output voltage excitation of pressure sensors (+)
- □ 26 AIN COM: common terminal for pressure sensors (-), connected to the internal mass of the board

The optional analogue measurement acquisition module is able to perform potential measurements, temperatures (max 2) and pressures (max 2). The diagrams for the connections to the sensors are shown below:

### Pressure sensor connections:









### Temperature sensor connections:

Since there is no cable resistance compensation, it is recommended to use PT500 or PT1000 sensors if the cable length is more than one meter. The recognition of the sensor type (PT100 / 500/1000) is automatic.






### Connection of a pressure/temperature sensor:

Two different types of sensors can be connected, a pressure sensor and a temperature sensor.

For the temperature sensor, because there is no compensation of cable resistance, we recommend the use of PT500 or PT1000 sensors if the cable length is more than one meter. The recognition of the sensor type (PT100 / 500/1000) is automatic.



N.B: the pressure sensor MUST BE connected to input 1 and the temperature sensor MUST BE connected to Input 2!




### **OUTPUTS CONNECTIONS**

### Digital output connections on the basic board (OUT01, OUT02, OUT COM)

The outputs are not polarized, therefore connection schemes can be adopted to positive or to common negative, as reported by the following diagram.

- OUT 01 = output 1
- ☐ OUT 02 = output 2
- □ OUT COM = common outputs



- ☐ Opto-insulated output (Opto-MOS)
- Maximum switching voltage: 40V === /28V ~
- Maximum switching current:100mA
- Maximum Ron= 70 Ω
- $\square$  Maximum switching frequency (load RL= 24  $\Omega$ , VOUT=24  $\longrightarrow$  ): 50Hz
- ☐ Insulation from other secondary circuits: 500 V ===





### **USCITA 4-20MA**

The 4-20 mA output can be passive (powered from outside) or active, only when the power supply is installed. There are 3 output terminals available, the passive output uses AO + and AO- (the minimum operating voltage is 5V). When the power supply is present, it is also possible to select the active mode by connecting the load between the AO- and AOCOM terminals. In this case, the loop should not be powered. The passive mode is always available even with the power supply installed, use the AO + and AO- terminals. When the passive mode is used and the loop is powered, the instrument exits sleep mode and remains active for 10 seconds and then returns to sleep mode. This status change can only be repeated after 1 minute. For the connections to the terminal block see also "ELECTRICAL CONNECTION CONVERTER- SENSOR" pag. 28

- □ AO-: OUTPUT current to the connected device (active or passive mode).
- AO+: INPUT current from the connected device (passive mode, loop supply from external source).
- AOC: return of the OUTPUT current (active mode).




**ATTENTION:** the power supply of the loop supplies power only to the 4-20 mA output circuits and not to the whole device, which therefore remains active and consumes the batteries if it is not powered in any other way.

The 4-2mA output can have two operating modes:


PASSIVE MODE: the power is supplied by an external source. Connect the POSITIVE of the external source to the AO + terminal. Connect the LOAD to the AO- terminal.

ACTIVE MODE: the power is supplied by the card power supply (if fitted). Connect the LOAD to the AO- terminal. Connect the RETURN to the AOC terminal.

### **ACTIVE CONNECTION**



### **PASSIVE CONNECTION 1-2**



The maximum load value for the PASSIVE connection depends on the supply voltage supplied. The maximum 1000 ohms of load are guaranteed only with supply voltage> = 25V.



### ATTENTION! This output isn't galvanically insulated

Externally supplied loop power gives power to the 4-20 mA output circuits only and not to the whole device. When power is applied to the 4-20 mA loop and the device is powered by the batteries alone, the device will come out of the low-power mode and remain active for the time set in the "display time" function to allow the current value on the loop to be read. During this phase, battery consumption is very high




#### Energy saving algorithm diagram

The externally supplied power supply of the loop energizes only the 4-20 mA output circuits and not the whole device. When power is applied to the 4-20 mA loop and the device is powered only by the batteries, the latter will exit the low-power mode and remain active for a certain time (about 10 seconds) to allow the reading of the current value on the loop. During this phase the battery consumption is very high. To save energy, there is a current reading time of about 10 seconds every minute. Increasing the number of readings, the minimum time elapsing between one reading and the other is automatically increased by one minute at a time, according to the diagram shown below.

The energy saving algorithm is activated only for intervals of less than or equal to one minute. For longer times it does not activate. For example, by reading the current every two minutes, energy saving is not activated.

#### Simultaneous connection to digital input / output terminals on expansion module

The outputs and optional inputs on the expansion module share the same common terminals related to the card inputs and outputs. Since the input and output circuits have different common terminals, it is theoretically possible to use the same I / O terminal at the same time to read a signal via digital input and control a device via digital output. See the following diagram to understand how it works. The power supplies in this case must be separated if the possibility of simultaneous use of input and output is to be maintained.








### Optional digital inputs / outputs connections (04,I2, 03, I3, GND)

The digital output OUT 4 and the digital input INPUT 2 as the digital output OUT3 and the digital input INPUT 3 share the same terminal but have different municipalities, therefore the input and output circuits can be made independently 'from each other, as shown below for the OUT 3 / INPUT 3 scheme (OUT 4 / INPUT 2 are equivalent).




- ☐ O4 I2: digital output OUT 4 / digital input INPUT 2
- ☐ O3 I3: digital output OUT 3 / digital input INPUT 3
- GND: terminal connected to the protective earth (chassis) for connecting cable shields

**NOTES:** The digital outputs OUT 4 and OUT 3 use the OUTC terminal as common. The digital inputs INPUT 2 and INPUT 3 use the INC terminal as common.

#### **MIL CONNECTOR**

For details of connections with MIL connectors, refer to the manual: MV145-255\_ MIL. CONNECTOR POSITION





#### Notes on operation of out 4/20 mA

The MV255 ca	ın be equipped v	vith an analog	output that	provides a	a current :	signal <sub>l</sub>	proportional	to the flow	rate,	in the
standard range	e of 4 to 20 mA.									

The analog output can operate in two power modes:

- ☐ Active mode: powered by the optional internal power supply, enabling a permanent connection to external devices.
- ☐ Passive mode: powered by an external device connected to the analog output.

#### Passive mode: functioning

The analog output provides a valid 4–20 mA signal only under the following conditions:

- ☐ When the device is powered via USB or via the optional internal power supply.
- ☐ When battery-operated, and a valid voltage is applied to the analog output pins (AO+ and AO-) during a specific time frame, which can be configured using the Display Time function ("9.2" pag. 54).
- ☐ When battery-operated, and a valid voltage is applied to AO+ and AO- during the entire measurement cycle (typically 50 to 200 ms)

In all other cases, even if a correct voltage is applied to the output pins, the current remains fixed at approximately 24 mA, indicating that the device is connected, but the analog signal is not valid.

To minimize power consumption, the reading time of the 4–20 mA signal must be kept as short as possible. This time is configurable via the Display Time function (MCP KBTMT command) "9.2" pag. 54. For proper operation, it must be set between 5 and 59 seconds. **A value greater than 59 seconds disables the programmed 4–20mA operation** but still allows reading the 4–20 mA signal during the measurement cycle (from 50 to 200 ms).

After the last valid acquisition of the 4–20 mA signal, and after the electronics have been appropriately woken up for this purpose (i.e., when the KBTMT time expires), the electronics will no longer respond to subsequent read requests for the next 60 seconds.

Note: In any case, it is recommended to use the shortest possible time to acquire the analog signal.

When the power applied to the 4–20 mA output is continuous, the device activates the output for the configured display time and remains off for the rest period (60 seconds). At the next valid measurement cycle, the interface is reactivated. This is not the optimal scenario in terms of power consumption.

When the power is applied intermittently, i.e., at defined intervals (for example, every 10 minutes), the duty cycle is much lower, thus reducing the energy required from the battery. In this case, the measurement cycle latency time (typically 15 seconds) must be taken into account, so the total measurement acquisition time for the connected device must be sufficiently long to cover the entire cycle time (typically 15 seconds) plus the analog signal reading time.

#### Parameters to be set for optimal operation

Ш	MV145: KBTMT= 5s	(POS.9.2:	VISUALITATION	I IIM)


- □ ACQUISITION DEVICE (MASTER):
  - ☐ minimum measurement acquisition time: 15 s + real acquisition time
  - □ acquisition interval: as long as possible compatible with performance

The following is a diagram describing the operation and the values to be set











#### START VISUALIZATION PAGES




Direct exposure of the converter to sunlight may damage the liquid crystal display.

The display of the pages can be changed with respect to some enabled or disabled functions.



Press the button to change the display.











#### Press the button to change the display.







Press the button to change the display.








## **ACCESS TO THE CONVERTER**

## Meaning of flags

FLAG	DESCRIPTION	FLAG	DESCRIPTION
Ø	EMPTY PIPE	Ţ	MIN FLOW ALARM
	FILE UPLOAD	!/	MAX FLOW ALARM
	FILE DOWNLOAD	<b>\</b>	VIDEO TERMINAL CONNECTED
	BATTERY RECHARGE (FLASHING) LOW BATTERY (FIXED)	<u>Z!</u>	FLOW RATE OVERFLOW
	FLOW RATE SIMULATION (FLASHING)	Л1	PULSE 1 OVERFLOW
<b>+·</b> +	CALIBRATION (FLASHING)	Л2	PULSE 2 OVERFLOW
>!<	GENERIC ALARM (FLASHING)	•	
	GENERAL ALARM ONLY ON PHYSICAL DISPLAY (FLASHING)		POWERED DEVICE WITH ONE
<b>-</b> %-	SIGNAL ERROR		CHARGERS BATTERY (MID-DIRECTIVE)
-2-	EXCITATION ERROR		
2.11	2G NETWORK CONNECTION	цХл	MODEM IN NETWORK SEARCH / TOTAL ABSENCE OF
3.11	3G/4G NETWORK CONNECTION		SIGNAL



## **LED** interpretation



LED 1 CPU communication LED 2 CPU measures

- Red LED: Alarm signal
- Blue LED: Communication activated
- Green LED: System working correctly






#### **ACCESS TO THE CONFIGURATION MENU**

The configuration can be done in two different ways:

- 1) By keypad of converter
- 2) By MCP interface (Virtual display of instrument)

**NOTE:** An external power source is required for programming. (USB connection or power supply if the device is foreseen).

#### Access Via Keypad



#### **SHORT PRESSING (< 1 SECOND):**

Increases the numeric figure or the parameter selected by the cursor returns to the previous subject on the menu

#### LONG PRESSING (> 1 SECOND):

Decreases the numeric figure or the parameter selected by the cursor. Proceeds to the next subject on the menu.

#### SHORT PRESSING (< 1 SECOND):

Moves/positions the cursor rightward on the input field. Proceeds to the following subject of the menu. Change the display of the process data

### LONG PRESSING (> 1 SECOND):

Moves/positions the cursor leftward on the input field. Returns to the previous subject on the menu

#### SHORT PRESSING (< 1 SECOND):

Enter /leave the selected function enables the main menu for the instrument configuration Cancels the selected function under progress

#### LONG PRESSING (> 1 SECOND):

Leaves the current menu Enables the totalizer reset request (when enabled) Confirms the selected function.

#### Access Via Keypad (converter is connected to an external energy source)



#### ATTENTION! THIS FUNCTION LEADS TO AN HIGH ENERGY CONSUMPTION

To activate this function press the button "Enter" following sentence will be shown on the display:



for >10 seconds. When the keypad becomes active, the


#### "Programming active. Attention: high power consumption"

With this option activated it's allowed use the converter as if it is connected to an external power supply.




#### Access via mcp interface (virtual display)

MCP is a Windows® software that allows to set all the converter functions and personalize the menu. The MCP program is required for the blind version of the converter. To use MCP interface consult the relevant user manual.



#### FLOW RATE VISUALIZATION



This symbol appears (red color on the virtual display) only when the overall noise is over 2.5% of flow rate.

MV255 allows you to view the flow in 5 digits; this means that the maximum flow displayed on the display is equal to 99999 (regardless of the position of the decimal point). The minimum displayable value is instead limited to the number 0.0025. The unit of measurement that can be represented depends on the capacity / diameter of the sensor: the units allowed are those that, once the instrument's full-scale value is set, can be represented with a numeric field whose maximum value does not exceed 99999.

#### Example for DN 300:

- ☐ Full scale value: 3m / s
- ☐ Allowed units of measure (examples): I / s (216.00); m3 / h (777.60); m3 / s (0.2160) ...
- Measurement units NOT allowed (examples): I / h (777600)






#### Flow rate alert



Symbol that is activated when there is a dynamic variation of the flow measurement. It indicates that the measurement shown in the display is stabilizing.

### **QUICK START MENU**

The QUICK START MENU allows the user immediate access to some of the most frequently used functions; through the MCP software it is possible to customize this menu, in order to make it suitable for the specific application.



Pressing the enter button from the display pages, access to the Quick Start menu is immediate. If you press the enter button to access the Main menu directly, the Quick Start may have been disabled by the function POS "9.10" pag. 54.




#### **CONVERTER ACCESS CODE**

Access to instrument programming is regulated by six access levels. All functions are assigned to a specific access code and the functions are then grouped according to a logical criterion INSERT FUNCTION.

Access Code Set: Menu 13 System

The codes can be set from the instrument keyboard or via the MCP interface. Depending on the access level set, the menu functions will be displayed (see "MENU 13 - system" pag. 96. These access levels interact with the function POS "13.10" pag. 55 which enables its use.



#### Restricted Access Set: Menu 13 System

Restart access = ON: Access allowed only to functions of a specific level (POS "13.10" pag. 55).



THE VALUES THAT CAN BE SET FOR THE FUNCTION. "ACCESS RIST" ARE ON / OFF.

Example: If the operator has an access level code 3, after entering it, it can only modify the functions provided for an access level 3.

Access to restaurants = OFF: After entering the access code of a certain level, it allows you to modify the functions of the selected level and the functions with the lowest access level. Example: If the operator has the level 3 code, after having entered it, he will be able to modify all the functions of level 1,2,3.

\* WARNING: take careful note of the customized code, since there is no way for the user to retrieve or reset it if lost. Factory preset access codes:


- □ L1: 10000000
- ☐ L2: 20000000
- □ L3: 30000000
- □ L4: 40000000





The following example shows how to change the Full scale by Quick Start menu; the second illustrates how to change the function by the Main menu.

## EXAMPLE: modifying the full scale value from 4dm³/s to 5dm³/s, from the "Quick start menu"



Press the ENTER button to access the Quick Start menu



Select this function in the list to be edited



Press the ENTER button to select the function.



Select the value to be changed




Change the value



Confirm the new value



Long Push




Main Page



## EXAMPLE: modifying the full scale value from 4dm³/s to 5dm³/s, from the "Main Menu" (quick start menu enabled)

**Quick Start** 



Press the ENTER button to access the menu




Press arrow keys to select the cell in which to insert the number of the access code.




Press ENTER button to confirm value.




Press the ENTER button to access the Main Menu




Press the ENTER button to access the "Scale Menu"



Select the value to be changed



Press the ENTER button Confirm the new value




Press Esc




Select "Main Menu"




Select function




Press the ENTER button to access the "Fs1"



Change the value



Press Esc



Main page





## **FUNCTIONS MENU**

The main menu is selected from the Quick start menu by pressing the key and entering the access code; enter the access code if required. Note: some function here below are displayed only with other functions active, or with optional modules.

MAI	N MENU Sensor			
3-	Scales			
3-	SENSOR			
5- 6- 7- 8- 9-	S.model	0	1.1	Sensors model
8-	Lining	UNSPEC.	1.2	Flow sensor lining material type
10	S.type	FULLBORE	1.3	Type of sensor: fullbore or insertion
1.1	U.type	METRIC	1.4	Type of measure units for sensor parameter: metric or imperial
13-	Diam.	00700	1.5	Sensor's nominal/real diameter DN (0-2500)
	KA	+00.9637	1.6	Sensor coefficient KZ (zero point)
	KA-	-44904	1.7	Calibration data of sensor for negative flow
	KZ	-18852	1.8	Sensor coefficient KZ (zero point)
	KD	+00.4014	1.9	Sensor coefficient KD
	Ins.position	0	1.10	Insertion position
	KP dynamic	OFF	1.11	KP dynamic, coefficient for insertion
	Ki	10000	1.12	Sensor coefficient Ki
	Кр	10000	1.13	Sensor coefficient Kp
	KC	100000	1.14	Sensor coefficient KC
	C.Curr.	mA025.0	1.15	Sensor excitation current
	C.Reg. PB	ms03	1.16	Current regulator proportional band
	C.Reg.DK	stp 005	1.17	Current regulator derivation constant
	C.R.time	ms03	1.18	Measure sampling frequency
	E.P.Detect	ON	1.19	Enables the empty pipe detection feature
	Z max	Kohm 0500	1.20	Empty pipe detection threshold
	S.err.delay	10	1.21	Signal error delay (n. sample)
	Sens.verify	OFF	1.22	Automatic sensor verify enable
	KL	00.+000000	1.23	Linearization coefficient
	Zero point cal.		1.24	Pipe hydraulic zero calibration

**SENSOR** 

MATI	N MENII			
1-3	Sensor			
3-	Scales			
5-1	Measure HNITS			
6-1				
8-R	Diam.	m m	2.1	Nominal diameter measure unit
123	S.cable	m	2.2	Cable length on separate version
11-1	FR.unit	METRIC	2.3	Flow rate type measure unit: metric or imperial
127	Pis1 u.	METRIC	2.4	Pulse 1 type measure unit: metric or not metric
10	Pis2 u.	METRIC	2.5	Pulse 2 type measure unit: metric or not metric
_	T+ unit	METRIC	2.6	Total direct totalizer measure unit type: metric or imperial
	T+ unit	(m3)	2.7	Total direct totalizer measure unit
_	T+ D.P.	4	2.8	Total direct totalizer decimal point position
_	P+ unit	METRIC	2.9	Partial direct totalizer measure unit type: metric or not metric
_	P+ unit	(m3)	2.10	Partial direct totalizer measure unit
_	P+ D.P.	4	2.11	Partial direct totalizer decimal point position
_	T- unit	METRIC	2.12	Total reverse totalizer measure unit type: metric or not metric
_	T- unit	(m3)	2.13	Total reverse totalizer measure unit
_	T- D.P.	4	2.14	Total reverse totalizer decimal point position
_	P- unit	METRIC	2.15	Partial reverse totalizer measure unit type: metric or not metric
_	P- unit	(m3)	2.16	Partial reverse totalizer measure unit
_	P- D.P.	4	2.17	Partial reverse totalizer decimal point position
_	Temp.unit	٥C	2.18	Temperature measure
_	Mass units	ON	2.19	Enable/disable the selection of mass units on full scale set
_	Sg	(kg/dm3)	2.20	Specific gravity coefficient
	AIN1 m.u.	1,107:MCPI	2.21	Unit of measurement for analogue input 1
	AIN2 m.u.	1,107:MCPI	2.22	Unit of measurement for analogue input 2

**UNITS** 



## **SCALES**

#### MAIN MENU 1-Sensor 2-Units 3-Scales 4-Measure 5-Alarms SCALES FS1 dm3/s 5.00 3.1 Full scale flow rate 1 PIs1 dm3 0.15 3.2 Full scale flow rate 2 Tpls1 (ms) 3.3 Duration of the pulse generated on channel 1 PIs2 dm30.15 3.4 Pulse value on channel 2 Tpls2 15."(ms)" 3.5 Duration of the pulse generated on channel 2 $\,$ AIN1 1,107:MCPI 3.6 Analog input scale 1 SHIA 1,107:MCPI 3.7 Analog input scale 2

## **MEASURE**

MAIN MENU 1-Sensor 2-Units 3-Scales 4-Measure 5-Alarms			
6-Inputs 7-Outputs			
<b>3</b> MEASURE			
19 Filt.bypass	ON	4.1	Measure filter bypass
12 Cut-off 13 Calverieu	00.0(%)	4.2	Measure cut-off threshold
13 Cal.verify	ON	4.3	Automatic calibration verify
H.imm.inp.	ON	4.4	High immunity inputs

# ALARMS dm3/s

## **ALARMS**

Max+	dm3/s	OFF	5.1	Max.pos.flow r.alarm threshold MAX+
Max-	dm3/s	OFF	5.2	Max.neg.flow r.alarm threshold MAX-
Min+	dm3/s	OFF	5.3	Min.pos.flow r.alarm threshold MIN+
Min-	dm3/s	OFF	5.4	Min.neg.flow r.alarm threshold MIN-
Qhyst		200003	5.5	Hysterisis on f.rate alarm threshold
A1Mx		O	5.6	MAX alarm threshold for analog input 1
A1Mn		O	5.7	MIN alarm threshold for analog input 1
Aith	KPa	0.00	5.8	AIN1 MIN alarm threshold
A2Mx		O	5.9	MAX alarm threshold for analog input 2
A2Mn		O	5.10	MIN alarm threshold for analog input 2
Aizh	KPa	0.00	5.11	Hysterisis on a. in.2 al. thr
_	_	_	_	





## **INPUTS**

MAIN MENU 1-Sensor 2-Units 3-Scales 4-Measure 5-Alarms 6-Inputs			
INPUTS			
SINPUTS  10 T+ reset  12 P+ reset	OFF	6.1	Total direct (positive) flow totalizer reset enable
12-1 P+ reset	OFF	6.2	Partial direct (positive) flow totalizer reset enable
T- reset	OFF	6.3	Total reverse (negative) flow totalizer reset enable
P- reset	OFF	6.4	Partial reverse (negative) flow totalizer reset enable
Count lock	OFF	6.5	Totalizer counting lock command
Meas.lock	OFF	6.6	Measure zero lock command
Calibration	OFF	6.7	Calibration external command
Sys.v.detect	ON	6.8	System violation detect
D.In2	SYS.VIOL.	6.9	Digital input 2 function
D.In3	OFF	6.10	Digital input 3 function

# **OUTPUTS**

## COMMUN.

MAIN MENU			
1-Sensor 2-Units			
3-Scales			
4-Measure			
5-Alarms			
2-0utputs			
8-Communication			
.9-Display			
OUTPUTS			
13-10ut1	F.R.SIGN	7.1	Output 1 function selection
Out1 inv.	ON	7.2	Output 1 inverted status
Out1 pls.	ON	7.3	Output 1 pulsed status
Out2	AIN1 MX/MN	7.4	Output 2 function selection
Out2 inv.	ON	7.5	Output 2 inverted status
Out2 pls.	ON	7.6	Output 2 pulsed status
Out3	MAX.AL+	7.7	Output 3 function selection
Out3 inv.	ON	7.8	Output 3 inverted status
Out3 pls.	ON	7.9	Output 3 pulsed status
Out4	MAX.AL+	7.10	Output 4 function selection
Out4 inv.	ON	7.11	Output 4 inverted status
Out4 pls.	ON	7.12	Output 4 pulsed status
Out mA1	4-20 +/-	7.13	Analog current output 1 range
A1S	dm3/s	7.14	Full scale value for analog out1

COMMUNICATIONS
Comm.proc.abort
Send status
Send DL format
Send ST format
Send proc.data
Send events
Send alarms
Send I.data
Send s.test
Send config.
Send fn.enable
Send qs.list
RTC sync.req.

8.1	Communication process abort
8.2	Send device status information
8.3	Send data logger fields format
8.4	Send s.test data fields format]
8.5	Send instantaneous process data
8.6	Send last system logged events
8.7	Send system alarms information
8.8	Send last logged process data
8.9	Send last sensor test data
8.10	Send parameters config.data
8.11	Send functions enable status
8.12	Send quick start func.list]
8.13	Request a RTC synchronization





RTC sync.req. Check m.box FTP download ON 8.16 FTP upload FTP download ON 8.16 FTP upload FTP download ON 8.17 FTP upload FTP download ON 8.18 FTP upload FTP download ON 8.18 FTP upload FTP download ON 8.19 FTP download indice enable FTP download ON 8.19 FTP download indice enable FTP upload FTP download ON 8.19 FTP upload FTP download ON 8.19 FTP upload FTP download ON 8.19 FTP upload FTP upl	MAIN	MENU			
RTC Sunc.req. Check m.box FTP download Mail send Mail rec. OH 8.16 FTP download FTP download FTP download ON 8.16 FTP download ON 8.16 FTP download FTP download ON 8.17 FTP download FTP download FTP download RMt.pp.acl Comnecton test access five least and self-access print access access to evel FTP download RMt.pp.acl FTP download RMt.pp.acl Compressed active password Comnecton test access Remote good inciden enable FTP download RMt.pp.acl FTP download RMt.p	2-1				
RTC sync.req. Check m.box FTP dounload Mail send Mail rec. FTP pload RTC sync.req. Check m.box FTP dounload Mail send Mail rec. OH S.17 FTP dounload N S.18 FTP dounload N S.17 Mail receive function enable FTP dounload RTC sync.req. FTP dounload OH S.17 FTP dounload OH RTC sync.req. OH S.17 Mail receive function enable FTP dounload OH RTC sync.req. FTP dounload OH S.17 FTP dounload OH S.17 FTP dounload OH S.17 FTP dounload OH S.17 FTP dounload OH S.18 FTP dounload inchain enable FTP dounload OH RTC sync.req. OH S.17 Mail receive function enable FTP dounload OH S.18 FTP dounload inchain enable FTP dounload OH S.19 FTP dounload inchain enable FTP dounload OH S.19 FTP dounload inchain enable FTP dounload OH S.17 FTP dounload inchain enable FTP dounload inchain enable FTP dounload OH S.18 S.20 Remote operations access level FTP dounload OH S.21 Compensed archive password Compressed archive password Occupies and Automatic events send on alarms Access point authentication type OFF S.26 Access point authentication type OFF S.26 Access point authentication type Access point authentication type Access point authentication type OFF S.26 Access point authentication OFF S.27 Access point authentication OFF S.27 Access point authentication OFF S.27 Access p		leasure			
RTC synor.req. Check m.box FTP download ON 8.15 FTP download Secure Check malbox for new male FTP download Mail send ON 8.16 FTP upload FTP upload FTP download FTP download FTP download ON 8.17 FTP upload Secure Check malbox for new male FTP upload FTP download FTP download FTP download ON 8.18 FTP upload function enable FTP upload Secure Check malbox for new male FTP upload function enable FTP upload function enable FTP upload function enable FTP upload function enable FTP download function enable FTP upload function enable FTP commands Secure Check malbox for new male FTP upload function enable FTP download function enable FTP enable FTP password Amathamama secure enable ITP password Access point password Access point user name Access point user name HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH	6-1	nputs			
RTC Synchreq. Check m. box FTP download Nail send Nail s	8=0	<u>ommunication</u>			
Check m.box FTP dounload Mail send Mail rec. ON 8.15 FTP dounload Mail send Mail rec. ON 8.17 Mail receive function enable FTP upload FTP pload ON 8.17 FTP upload FTP dounload ON 8.18 FTP upload function enable FTP dounload RMt.op.acl File compr. ON 8.21 File compression enable status Conn.test ON 8.23 Connection test enable Conn.test ON 8.23 Connection test enable Conn.test ON 8.24 Connection test enable Auto Ev. snd Access p.n.ame Auth.type User name USer password SMTP User SMTP Sew. HHHHHHHH 8.23 Consession trained status Connection test enable Connection test enable SMTP User SMTP User SMTP User SMTP Sew. HHHHHHHHH 8.25 Consess point authentication type Connection test enable Co	10-Î	ata lawaan		8.13	Request a RTC synchronization
FTP download Mail send Oh Ail send Mail rec. Oh FTP upload Oh FTP upload Oh Ail send FTP download function enable FTP events FTP server HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH	12-I 13-5				
Mail rec.  FTP upload  ON 8.18 FTP upload inches experience of Access point user experience of Access point user and a upload in the property of the password of SMTP upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload in upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload inches experience of Access point user and a upload in up	- 1		ON	8.15	FTP download execute command
FTP upload FTP download Rmt.op.acl I 8.19 FTP download ON 8.19 FTP download FTP download function enable Rmt.op.acl I 8.20 Remote operations access level File compr. ON 8.21 File compression enable status ZIP password Conn.test ON 8.23 Connection test enable Auto Eu.snd ON 8.24 Automatic events send on aiams Access p.name HHHHHHHHH 8.25 Access point aufentication type User name User password ShTP User HHHHHHHHH 8.29 User name HHHHHHHH 8.29 User name User password ShTP User HHHHHHHHHH 8.30 HHHHHHHHH 8.30 HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		Mail send	ON	8.16	Mail send function enable
FTP download Rmt.pp.acl 1		Mail rec.	ON	8.17	Mail receive function enable
RMT.Op.acl File compr. ON 8.21 File compression anable status ZIP password HHHHHHHH 8.22 Compressed archive password Conn.test ON 8.23 Connection test enable Auto Ev.snd ON 8.24 Automatic events send on alarms Access p.name HHHHHHHH 8.25 Access point authentication type User name HHHHHHHHH 8.27 Access point authentication type User name HHHHHHHHHH 8.28 Access point authentication type User name HHHHHHHHHH 8.29 Access point authentication type User name HHHHHHHHHH 8.29 Access point authentication type User name HHHHHHHHHHHHH 8.29 Access point authentication type User name for SMTP service SMTP psw. HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		FTP upload	ON	8.18	FTP upload function enable
File compr.  ZIP password Conn.test ON 8.23 Connection test enable ON 8.24 Automatic events send on alarms Access p.name HHHHHHHH 8.25 Access point authentication type User name User password User password HHHHHHHHH 8.26 Access point authentication type User name User password HHHHHHHHH 8.28 Access point authentication type User name User password HHHHHHHHH 8.29 User name for SMTP service SMTP User HHHHHHHHH 8.30 Password for SMTP service SMTP psw. HHHHHHHHH 8.31 User name for POP3 service FTP User HHHHHHHHH 8.31 User name for POP3 service FTP User HHHHHHHHH 8.31 User name for POP3 service FTP password HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					FTP download function enable
ZIP password Conn.test 0H 8.22 Compressed archive password Conn.test 0H 8.23 Connecton lest enable Auto Ev.snd 0H 8.24 Automatic events send on alarms Access p.n.ame HHHHHHHHH 8.25 Access point authentication type User name HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		•	-		·
Conn.test Auto Ev.snd ON 8.24 Automatic events send on alarms Access p.name Auth.tupe OFF 8.26 Access point name Auth.tupe User name User password HHHHHHHH 8.27 Access point user name User password SMTP User HHHHHHHHH 8.29 User name for SMTP service SMTP psu. HHHHHHHHH 8.31 User name for FOP3 service POP3 User HHHHHHHHH 8.31 User name for POP3 service POP3 User HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					·
Auto Eu.snd Access p.name Auth.type OFF S.26 Access point aufferitication type User name HHHHHHHH B.27 Access point aufferitication type User name User password HHHHHHHHH B.29 User name User password HHHHHHHHH B.20 User name for SMTP service SMTP User HHHHHHHHH B.20 User name for SMTP service SMTP psw. HHHHHHHH B.20 User name for SMTP service SMTP psw. HHHHHHHH B.30 Password for SMTP service POP3 User HHHHHHHHH B.31 User name for POP3 service POP3 psw. HHHHHHHHH B.32 Password for POP3 service Password for FOP3 service User name for FTP service Password for FTP service FTP password HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					
ACCESS P.Name Auth.type OFF OFF OFF OFF OFF OFF OFF OFF OFF OF					
Auth.type User name User password SMTP User HAHRHRHH S.27 Access point user name User password SMTP User HAHRHRHH S.29 User name for SMTP envice SMTP psw. HAHRHRHH S.30 Password for SMTP envice POP3 User HHHHHHHH H S.31 User name for SMTP envice POP3 service POP3 psw. HHHHHHHHH H S.31 User name for POP3 service POP3 psw. HHHHHHHHH H S.32 Password for POP3 envice Password for FTP service Password for FTP service WHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					
User name User password POP3 User HHHHHHHH User User password HHHHHHHH User User password HHHHHHHH User User password HHHHHHHHH User HHHHHHHHHH User HHHHHHHHHHH User HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					•
User password SMTP User SMTP psw. SMTP psw. SMTP psw. SMTP psw. POP3 User SMTP psw. SMTP pssword SMTHHHHHHH SMA SMA SMAC Password for FTP service SMAC Main.sig.nthr ON SMAC Maintenna signal threshold First Maintenna SMAC Maintenna Signal threshold SMAC Maintenna Signal threshold First Maintenna SMAC Maintenna Signal threshold First Secure Connection Instrument Identifier Sting First Secure Maintenna SMAC Maintenna SM					, ,,
SMTP psw. POP3 User HHHHHHHH HHHHHHHHHHHHHHHHHHHHHHHHHHH				8.28	·
POP3 User POP3 psw. HHHHHHHH H HHHHHHHHHHHHHHHHHHHHHHHHH		SMTP User	XXXXXXXX	8.29	User name for SMTP service
POP3 psw. HAHAHAHA 8.32 Password for POP3 email service FTP User HAHAHAHAH 8.33 User name for FTP service FTP password HAHAHAHAH 8.34 Password for FTP service Min.sig.thr ON 8.35 Min.antenna signal threshold Primary DNS 000.000.000 8.36 Primary Domain Name Server Secondary DNS 000.000.000 8.37 Secondary Domain Name Server Retries 3 8.38 Max.number of session retries Instr.ID HAHAHAHAH 8.39 Instrument identifier string HELO string HAHAHAHAH 8.40 HELO identification string Sender addr. HAHAHAHAH 8.41 Email address of receiver 1 Receiver 1 HAHAHAHAH 8.42 Email address of receiver 1 Receiver 2 HAHAHAHAH 8.43 Email address of receiver 1 Receiver 2 HAHAHAHAH 8.44 SMTP mail send server name SMTP server HAHAHAHAH 8.45 SMTP secure connection layer SMTP port 25 8.46 SMTP mail send server port num. POP3 server HAHAHAHAH 8.47 POP3 mail receive server name POP3 si SSL/TLS 8.48 POP3 secure connection layer FTP server HAHAHAHAH 8.50 FTP server connection layer FTP server HAHAHAHAH 8.50 FTP server name or address FTP port 21 8.51 FTP server name or address FTP port 51 STP server name or address FTP data HAHAHAHAH 8.50 FTP server name or address FTP commands HAHAHAHAHAH 8.51 FTP root directory for commands Cert.check ON 8.55 FTP root directory for commands Cert.check ON 8.56 Server identity certificheck NTP time server name Tref WYYY/MM/DD 8.58 Data send time reference		SMTP psw.	XXXXXXXX	8.30	Password for SMTP email service
FTP User  HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		POP3 User	XXXXXXXX	8.31	User name for POP3 service
FTP password Min.sig.thr ON 8.35 Min.antenna signal threshold Primary DNS 000.000.000 8.36 Primary Domain Name Server Secondary DNS 000.000.000 8.37 Secondary Domain Name Server Retries 3 8.38 Max.number of session retries Instr.ID HARHHHHHH 8.39 Instrument identifier string HELO string HAHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		POP3 psw.	XXXXXXXX	8.32	Password for POP3 email service
Min.sig.thr Primary DNS OOO.000.000 Secondary DNS OFF Secondary Domain Name Server Secondary Domain Name Server Secondary DNS OOO.000.000 Secondary DNS OOO.000.000 Secondary DNS OFF Secondary Domain Name Server Secondary Domain Name Secondary Domain Name Server Secondary Domain Name Secondary Domain Na					<del></del>
Primary DNS Secondary DNS O00.000.000 Secondary DNS O00.000.000 Retries 3 8.38 Max.number of session retries Instr.ID HAWHHHHH 8.39 Instrument identifier string HELO string HAWHHHHH 8.40 HELO identification string Sender addr. HAWHHHHHH 8.41 Email address of sender Receiver 1 HAWHHHHH 8.42 Email address of sender Receiver 2 HAWHHHHHH 8.43 Email address of receiver 1 Receiver 2 HAWHHHHHH 8.44 SMTP mail send server name SMTP server HAWHHHHHHHH 8.45 SMTP secure connection layer SMTP port 25 8.46 SMTP secure connection layer POP3 server HAWHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					
Secondary DNS 000.000.000 8.37 Secondary Domain Name Server Retries 3 8.38 Max.number of session retries Instr.ID HAWAWAWA 8.39 Instrument identifier string HELO string WAWAWAWAWA 8.40 HELO identification string Sender addr. WAWAWAWAWA 8.41 Email address of sender Receiver 1 WAWAWAWAWA 8.42 Email address of receiver 1 Receiver 2 WAWAWAWAWA 8.43 Email address of receiver 2 SMTP server WAWAWAWAWA 8.44 SMTP mail send server name SMTP sl OFF 8.45 SMTP secure connection layer SMTP port 25 8.46 SMTP mail send server port num. POP3 server WAWAWAWAWA 8.47 POP3 mail receive server name POP3 sl SSL/TLS 8.48 POP3 Secure connection layer POP3 port 995 8.49 POP3 mail receive server name POP3 port 8.50 FTP server name or address FTP secure WAWAWAWAWA 8.50 FTP server name or address FTP secure ON 8.52 FTP secure connection enable FTP data WAWAWAWAWAWAWAWAWAWAWAWAWAWAWAWAWAWAWA		_			· ·
Retries Instr.ID XXXXXXXX X X X X X X X X X X X X X X		_			-
Instr.ID XXXXXXXX 8.39 Instrument identifier string HELO string XXXXXXXX 8.40 HELO identification string Sender addr. XXXXXXXX 8.41 Email address of sender Receiver 1 XXXXXXXXX 8.42 Email address of receiver 1 Receiver 2 XXXXXXXXX 8.43 Email address of receiver 2 SMTP server XXXXXXXXX 8.44 SMTP mail send server name SMTP sI OFF 8.45 SMTP secure connection layer SMTP port 2.5 8.46 SMTP mail send server port num. POP3 server XXXXXXXXX 8.47 POP3 mail receive server name POP3 sI SSL/TLS 8.48 POP3 Secure connection layer POP3 port 995 8.49 POP3 mail receive server name FTP server XXXXXXXXXX 8.50 FTP server port number FTP secure ON 8.52 FTP secure connection enable FTP data XXXXXXXXXX 8.53 FTP root directory for data FTP events XXXXXXXXXX 8.55 FTP root directory for commands Cert.check ON 8.56 Server identity certif.check NTP server XXXXXXXXXXXX 8.57 NTP time server name Tref WYY/MM/DD 8.58 Data send time reference		_			
HELO string Sender addr. Receiver 1 Receiver 2 RHXHXHXHH Receiver 2 SMTP server SMTP server SMTP port POP3 server HHXHXHHHH ROP3 server HHXHHHHHH ROP3 server HHXHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					
Sender addr. Receiver 1 Receiver 2 RHHRHRHR 8.42 Email address of receiver 1 Receiver 2 SMTP server SMTP server SMTP sl SMTP port SMTP p					•
Receiver 2 SMTP server HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		_		8.41	•
SMTP server SMTP sl OFF SMTP port SMTP mail send server port num. SMTP serve		Receiver 1	XXXXXXXX	8.42	Email address of receiver 1
SMTP sl SMTP port SMTP mail send server port num. SMTP mail send server port num. SMTP mail receive server name SMTP mail receive server name SMTP mail receive serve port num. SMTP server SMTP mail receive serve port num. SMTP server mame or address SMTP mail send server port num. SMTP mail receive serve port num. SMTP server mame or address SMTP mail send server port num. SMTP server port num. SMTP server mame or address SMTP server port num. SMTP server mame or address SMTP server port num. SMTP server mame or address SMTP server port num. SMTP server mame or address SMTP server port num. SMTP server mame or address SMTP server port num. SMTP server po		Receiver 2	XXXXXXXX	8.43	Email address of receiver 2
SMTP port POP3 server HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		SMTP server	XXXXXXXX	8.44	SMTP mail send server name
POP3 server POP3 sl SSL/TLS 8.48 POP3 Secure connection layer POP3 port 995 8.49 POP3 mail receive serve name POP3 mail receive server name					•
POP3 sl SSL/TLS 8.48 POP3 Secure connection layer POP3 port 995 8.49 POP3 mail receive serv.port num. FTP server HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					•
POP3 port S95 8.49 POP3 mail receive serv.port num. FTP server HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					
FTP server  RXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX					•
FTP port PTP secure ON 8.52 FTP secure connection enable FTP data HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					•
FTP secure ON 8.52 FTP secure connection enable FTP data HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH					
FTP events HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		FTP secure	OH	8.52	FTP secure connection enable
FTP commands HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		FTP data	*****	8.53	FTP root directory for data
Cert.check NTP server HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH		FTP events	XXXXXXXXXX	8.54	FTP root directory for events
NTP server XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX			****	8.55	FTP root directory for commands
T.ref YYYY/MM/DD 8.58 Data send time reference					-
InMsTm 0:00 8.59 Incoming message check time ProcST 0:00 8.60 Process data send time					
LogDST 0:00 8.60 Process data send time					
S.Compl.file ON 8.62 Send only complete file		_			
Alarm time 0:00 8.63 Alarm minimum send time interval					
SMS F.en ON 8.64 SMS functions global enable					
Auth.number 1234 8.65 Authorized incoming phone number		Auth.number	1234	8.65	Authorized incoming phone number
Mess.recv.1 1234 8.66 Short messages receiver 1		Mess.recv.1	1234	8.66	Short messages receiver 1
Mess.recu.2 1234 8.67 Short messages receiver 2				_	9
Mess.recv.3 1234 8.68 Short messages receiver 3		Mess.recv.3	1234	8.68	Short messages receiver 3

## COMMUN.

## **DISPLAY**

## DATA LOGGER

## **FUNCTION**

DISPLAY			
Language	EN	9.1	Language for all messages
Disp.time	S	9.2	Display/keyboard inactivity time
D.rate		9.3	Display refresh rate
Disp.fn.	1	9.4	Display function number
Disp.lock	OFF	9.5	Display function selection lock
Part.tot.	ON	9.6	Partial totalizers enable
Neg.tot.	ON	9.7	Negative totalizers enable
Net tot.	ON	9.8	Net totalizers enable
Disp.date	ON	9.9	Time and date display enable
Quick start	OFF	9.10	Quick start menu enable
-Display -Data logger -Functions -Diagnostic -System	_		

DATA LOGGER			
D.logger en.	ON	10.1	Data logger enabling
Meas.units	ON	10.2	Measure unit recording enable
Field separ.	;	10.3	Field separator character
Decim.separ.		10.4	Decimal separator character
Interv.	0:01:00	10.5	Sampling interval
Log T+	OFF	10.6	Totalizer Total Positive Enable T+
Log P+	OFF	10.7	Totalizer Partial Positive Enable P+
Log T-	OFF	10.8	Totalizer Total Negative Enable T-
Log P-	OFF	10.9	Totalizer Partial Net Enable P-
Log TN	OFF	10.10	Totalizer Total Net Enable
Log PN1	OFF	10.11	Totalizer Partial Net Enable
Log Q(UM)	OFF	10.12	Flow rate in Technical Units Enable
Log Q(%)	OFF	10.13	Flow rate in Percentage Enable
Log AL.EV	OFF	10.14	Alarm Events Enable
Log ADM	OFF	10.15	Additional Measures Enable
Log STR	OFF	10.16	Sensor Test Results Enable
Log BTS	OFF	10.17	Board TemperatureS Enable
Log IBV	OFF	10.18	Internal Board Voltages
Log EDC	OFF	10.19	Electrodes DC Voltages Enable
Log EAC	OFF	10.20	Electrodes AC voltages Enable
Log EIZ	OFF	10.21	Electrodes Source Impedance Enable
Log SCV	OFF	10.22	Sensor Coils Values Enable
8-Communication 9-Display 10-Data logger			

FUNCTION			
T+ reset	ON	11.1	Volume Totalizer Total Positive Reset
P+ reset	ON	11.2	Volume Totalizer Partial Positive Reset
T- reset	;	11.3	Volume Totalizer Total Negative Reset
P- reset		11.4	Volume Totalizer Partial Negative Reset
Load Sens.P.deP	0:01:00	11.5	Load Factory Default Sensor Data
Load Conv.P.deF	OFF	11.6	Load Factory Default Converter Data
Save Sens.P.deF	OFF	11.7	Save Factory Default Sensor Data
Save Conv.F.deF	OFF	11.8	Save Factory Default Converter Data
Calibration	OFF	11.9	CALibration Immediate Command
7-Outputs 3-Communication 9-Display			



11-Functions 12-Diagnostic 13-System

DIAGNOSTIC Self test Display test Verif. Sens.verify Flow sim. OFF Diag.sys.val. Display measures Disp.comm.vars SMS test SMTP conn test POP3 conn.test FTP conn.test Display graphs SD card info Firmware info S/N 0 ИΤ 000:00:00:00 TC 0

12.1	Auto test Immediate Command
12.2	Execute bit pattern test display
12.3	Sensor Verify Command
12.4	Measure Simulation Enable
12.5	Diagnostic system values
12.6	Diagnostic Measure VaLues
12.7	Diagnostic Communication Values
12.8	Short Message Test
12.9	SMTP Connection Test
12.10	POP3 Connection Test
12.11	FTP Connection Test
12.12	Oscilloscope function
12.13	SD memory Status
12.14	Model and Software Version
12.15	Serial Number

12.16 Total Working Time

Total Measure Cycles

12.17

# **SYSTEM**

**DIAGNOSTIC** 

SYSTEM	
Dayl.saving	ON
Time zone	+00.00
Date/time	///00:00:00
L1 code	*****
L2 code	*****
L3 code	*****
L4 code	*****
L5 code	*****
L6 code	*****
Restr.access	OFF
Device IP addr	63015504
Client IP addr	11.012.012
Network mask	255.255.254
KT	0.97882
KS	100.000
KR	100.000
DAC1 4mA	2460
DAC1 20mA	11050
AIN1 SS	0
AIN1 FS	20000
AIN2 SS	0
AIN2 FS	20000
Stand-by	
FW update	

Outputs
Outputs
Communication
Display
Data logger
Functions
Diagnostic
System

<ul> <li>13.1 Daylight Saving Time Enable</li> <li>13.2 Time zone</li> <li>13.3 Date and Time</li> <li>13.4 Level 1 Access CoDe</li> <li>13.5 Level 2 Access CoDe</li> <li>13.6 Level 3 Access CoDe</li> </ul>	
13.3 Date and Time 13.4 Level 1 Access CoDe 13.5 Level 2 Access CoDe	
13.4 Level 1 Access CoDe 13.5 Level 2 Access CoDe	
13.5 Level 2 Access CoDe	
13.6 Level 3 Access CoDe	
10.0 25/0/ 25000 0020	
13.7 Level 4 Access CoDe	
13.8 Level 5 Access CoDe	
13.9 Level 6 Access CoDe	
13.10 ReStricted Access Rule Enable	
13.11 Device IP Address	
13.12 Client IPAddress	
13.13 Network MaSk	
13.14 Coefficient KT	
13.15 Coefficient KS	
13.16 Coefficient KR	
13.17 Current output 1 Calibration Point 1	
13.18 Current output 1 Calibration Point 2	
13.19 Analog input 1 Calibration Point 1	
13.20 Analog input 1 Calibration Point 2	
13.21 Analog input 2 Calibration Point 1	
13.22 Analog input 2 Calibration Point 2	
13.23 System StandbY	
13.24 Firmware update	





#### **FUNCTIONS DESCRIPTION**




Here below the explanation on how the rows of menu are described:





The following picture describes where to find the name of the MCP functions in MCP-software. More info see MCP manual.





#### **MENU 1 - SENSOR**

(POS. 1.1) Sensor MODeL [S.model xxx] AL4 [SMODL]

Enter the first two characters of the serial number of the sensor as on the sensor label.

(POS. 1.2) LIning MAterial Type [Lining= Unspec.] AL4 [LIMAT]

Flow sensor lining material type. (PFA; PU-TDI; ALON; PEEK; HR; PP; PA-11; PTFE-HT; PTFE).

(POS. 1.3) Sensor TYPE [S. type= FULL BORE] AL4 [STYPE]

Select the type of full-bore sensor or insertion. This function appears only if the sensor is not present in the standard sensor table parameters.

(POS. 1.4) Sensor Units TYPe [U.type= METRIC] AL4 [SUTYP]

Select type of measure unit of sensor's parameter. Values metric or imperial (inch).

(POS. 1.5) Pipe DIaMeter Value [Diam.= mm xxx] AL4 [PDIMV]

Select the nominal diameter of the sensor (0-2500). ND is written on the sensor label.

(POS. 1.6) Coefficient KA [KA= + xx.xxx] AL4 [CFFKA]

KA factor: calibration coefficient.

(POS. 1.7) Coefficient KA Negative [KA= - xx.xxx] AL4 [CFKAN]

KA factor: calibration coefficient for negative flow. This function is showed only if at least 1 negative KL value is set.

(POS. 1.8) Coefficient KZ [KZ= +/- xxxxx] AL4 [CFFKZ]

Sensor zero calibration factor.

(POS. 1.9) Coefficient KD [KD = +/-xxxxx] AL4 [CFFKD]

Calibration Dynamic Factor.

(POS. 1.10) Sensor Insertion POSition [Ins.position = x] AL4 [SIPOS]

Parameter that refers to the position of the insertion sensor. This function is activated when the function "1.3" pag. 50 is set to "insertion". See the insertion sensor manual for more details.

(POS. 1.11) Sensor Insertion Dynamic KP [KP dynamic = ON/OFF] AL4 [SIDKP]

KP dynamic coefficient. This function is activated when the function "1.3" pag. 50 is set to "insertion". See the insertion sensor manual for more details.

(POS. 1.12) Coefficient Ki [Ki = +/-xx.xxx] AL4 [CFFKI]

This function is activated when the function "1.3" pag. 50 is set to "insertion". See the insertion sensor manual for more details.

(POS. 1.13) Coefficient Kp [Kp= +/- xxxxx] AL4 [CFFKP]

This function is activated when the function "1.3" pag. 50 is set to "insertion". See the insertion sensor manual for more details.





(POS. 1.14) CoeFFicient KC

[KC = +/-xx.xxx]

AL4

[CFFKC]

Calibration Factor. This function is activated if the sensor model is NOT present on the sensors table standard parameters

(POS. 1.15) Coils EXCitation Current

[C.curr.= mA xxx.x]

AL4

[CEXCC]

Excitation coils current. This function is activated if the sensor model is NOT present on the sensors table standard parameters.

(POS. 1.16) Current Regulator PRop. Band

[C.Reg.PB=xxx]

AL4

[CRPRB]

Proportional band of coils current regulator. This function is activated if the sensor model is NOT present on the sensors table standard parameters

(POS.1.17) Coils Regulator DERivative constant

[C.Reg.DK=xxx]

AL4

[CRDER]

Derivative constant of coils current regulator. This function is activated if the sensor model is NOT present on the sensors table standard parameters

(POS. 1.18) Coils Current Rise TiMe

[C.R.time]

AL4

[CCRTM]

Coils current rise time.

(POS. 1.19) Empty Pipe Detection ENable

[E.P.Detect = ON]

AL3

[EPDEN]

Enables the empty pipe detection function. This function is useful to keep the meter lock to zero when the pipe become empty.

(POS. 1.20) Empty Pipe Detection THreshold

[Z max= Kohm xxxx]

AL4

[EPDTH]

Empty tube detection threshold value. This function is activated if the function is enabled POS "1.19" pag. 50

(POS. 1.21) Signal Error ALarm Time

[S.err.delay=m xxx]

AL4

[SEALT]

Delay before generating error. This function is useful to prevent unexpected lock to zero of measure caused by sporadic events (empty pipe, excitation error, signal error).

(POS. 1.22) Automatic Sensor VeriFy Enable

[Sens. verify= OFF]

AL3

[ASVFE]

Enable the Automatic sensor verification (see BIV optional function).

(POS. 1.23) CoeFFicient KL

[KL=XX +/- XXXXXXXXX]

AL4

[SETKL]

Flow linearization coefficient, reserved to the service. This command is only showed if SMODL = 000.

(POS. 1.24) SET KJ value

[Zero point cal]

AL4

[SETKJ]

This function appears only when the conditions set by the values assigned to the DYNRT and DYNST functions are met, in detail:

- ☐ The flow rate is stable below the value assigned to the DYNRT function.
- At least the value assigned to the DYNST function must have elapsed since the last significant change in flow rate above the DYNRT value.

When the above conditions are met, the zero point calibration function appears on the display.

ALL OF THESE FUNCTIONS ARE RESTRICTED TO SERVICE, so the values assigned to these functions cannot be set.



### **MENU 1 - SENSOR: ONLY MCP FUNCTIONS**

Sensor Coils TiMe A	[MCP ONLY]	AL4	[SCTMA]
Reference sensor coil time A			
Sensor Coils TiMe B	[MCP ONLY]	AL4	[SCTMB]
Reference sensor coil time B			
Sensor Coils RESistance	[MCP ONLY]	AL4	[SCRES]
Reference sensor coil resistance			
Sensor E1 Reference Resistance	[MCP ONLY]	AL4	[SE1RR]
Resistance value of E1 electrodes			
Sensor E2 Reference Resistance	[MCP ONLY]	AL4	[SE2RR]
Resistance value E2 electrodes			
Sensor Coils Temperature ReFerence	[MCP ONLY]	AL4	[SCTRF]
Sensor data reference temperature. Temperature mea instrument reference data for B.I.V. function The temp		•	
Note: the temperature must be estimated on the basis	s of the place of the sensor installa	ition.	
Automatic Sensor VeriFy Enable	[MCP ONLY]	AL3	[ASVFE]
Enables the BIV functioning (see MCS manual)			
SET KL values	[MCP ONLY]	AL4	[SETKL]
Linearization measure coefficients			
SET TK values	[MCP ONLY]	AL4	[SETTK]
Temperature coefficients			
SET KJ values	[MCP ONLY]	AL4	[SETKJ]

Value of manual zeroing





#### **MENU 2 - UNITS**

**WARNING:** The totalizer value is updated and changed depending on the setting of unit value. The scale change may cause accuracy loss depending of rounding up. For example, if T +=0,234 liters with 3 decimals, it become T +=0.001 m³ losing 0.234 liters in rounding up.

(POS. 2.1) Sensor DIameter Unit of Measure	[Diam.= mm]	AL2 [SDI	UM]
Sensor diameter unit of measure (mm or inch)			
(POS. 2.2) Sensor CAble length Unit of Measure	[S.Cable= m]	AL2 [SCAI	UM]

Sensor cable length for separate version. Select m or foot.

(POS. 2.3) Flow Rate Unit of Measure Type [FR. UNIT= METRIC] AL2 [FRMUT]

Flow rate type measure unit. Select metric or not metric (Imperial units)

(POS. 2.4) Pulse 1 Unit of measure Type [PL1 unit= METRIC] AL2 [PL1UT]

Impulse unit of measure 1: metric or non-metric (English and American units). This works if you function POS. "7.3" pag. 52 is set to the pulse value. Furthermore the value of this function manages the full scale values of the function "3.2" pag. 51

(POS. 2.5) Pulse 2 Unit of measure Type [PL2 unit= METRIC] AL2 [PL2UT]

Pulse unit of measure 2: metric or non-metric (English and American units). This works if you function POS. "7.6" pag. 52 is set to the pulse value. Furthermore the value of this function manages the full scale values of the function "3.4" pag. 51.

(POS. 2.6) Totalizer Total Positive Unit of measure Type [T+ unit= METRIC] AL2 [TTPUT]

This function sets the type of unit of measurement of the totalizer: metric or non-metric (English and American units).

(POS. 2.7) Totalizer Total Positive Unit of Measure [U.M.T+= dm³] AL2 [TTPUM]

This function sets the unit of measurement for the total direct totalizer. The choice of its values depends on the choice of the unit of measurement of the function POS. "2.6" pag. 50.

(POS. 2.8) Totalizer Total Positive Decimal Point position [T+ D.P.= x] AL2 [TTPDP]

Setting total direct totalizer decimal point position. Example: T+D.P.= 3 visualized value T+dm³ 0.000 / T+D.P.= 2 visualized value T+dm³ 0.00

(POS. 2.9)Totalizer Partial Positive Unit of measure Type [P+ unit= METRIC] AL2 [TPPUT]

This function sets the type of unit of measurement of the partial totalizer: metric or non-metric (English and American units).

(POS. 2.10) Totalizer Partial Positive Unit of Measure [P+ unit= dm³] AL2 [TPPUM]

This function sets the unit of measurement for the total total totalizer. The choice of its values depends on the choice of the unit of measurement of the function POS. "2.9" pag. 50



#### (POS. 2.11) Totalizer Partial Positive Decimal Point position

[N.d.P+=x]

AL2

[TPPDP]

Setting partial direct totalizer decimal point position. Example: P+D.P.= 3 visualized value P+dm³ 0.000 / P+D.P.= 2 visualized value P+dm³ 0.00

#### (POS. 2.12) Totalizer Total Negative Unit of measure Type

[T- unit= METRIC]

AL2

[TTNUT]

This function sets the type of unit of measurement of the total inverse totalizer: metric or non-metric (English and American units).

#### (POS. 2.13) Totalizer Total Negative Unit of measure Type

[T- unit= dm3]

AL2

[TTNUM]

This function sets the unit of measurement for the total inverse totalizer. The choice of its values depends on the choice of the unit of measurement of the function POS. "2.12" pag. 50.

#### (POS. 2.14) Totalizer Total Negative Decimal Point position

[T- D.P.= x]

AL2

[TTNDP]

Setting total reverse totalizer decimal point position. Example: T- D.P.= 3 visualized value T- dm³ 0.000; T- D.P.= 2 visualized value T- dm³ 0.00.

#### (POS. 2.15) Totalizer Partial Negative Unit of Measure

[P- unit= METRIC]

AL2

[TPNUT]

This function sets the type of unit of measurement of the inverse partial totalizer: metric or non-metric (English and American units).

#### (POS. 2.16) Totalizer Partial Negative Unit of Measure

[P- unit= dm3]

2 [

[TPNUM]

This function sets the unit of measurement for the inverse partial totalizer. The choice of its values depends on the choice of the unit of measurement of the function POS. "2.15" pag. 50

#### (POS. 2.17) Totalizer Partial Negative Decimal Point position

[P-D.P.=x]

,

[TPNDP]

Setting partial reverse totalizer decimal point position. Example: P- D.P.= 3 visualized value P-dm³ 0.000; P- D.P.= 2 visualized value P-dm³ 0.00.

#### (POS. 2.18) TeMPerature Unit of Measure

[Temp. unit= C°]

ΔΙ 2

[TMPUT]

Setting temperature measure unit.

#### (POS. 2.19) MaSS Units Enable

[Mass units= ON/OFF]

AL2

[MSSUE]

Enable or Disable the selection of mass unit of full scale set.

#### (POS. 2.20) Volume to Mass Specific Gravity Coefficient

[Sg= Kg/dm<sup>3</sup> x.xxxx]

AL2

[VMSGC]

Specific weight setting. This function is activated when the function is enabled POS."2.19" pag. 50.

#### (POS. 2.21) ANalog Input 1 measure Unit

[AIN1 m.u.]

AL2

[AIN1U]

Analog Input 1 measure Unit

#### (POS. 2.22) ANalog Input 2 measure Unit

[AIN2 m.u.]

AL2

[AIN2U]

Analog Input 2 measure Unit





#### **MENU 3 SCALE**

#### (POS. 3.1) Flow Rate Full Scale 1

[FS1=I/s xxxx.x]]

AL4

[FRFS1]

The full scale is used to indicate the maximum flow rate of the meter. The scale must be chosen carefully, since its value is used for many other parameters. There are three input fields for this parameter, from left to right:

1) unit of measure 2) unit of time 3) numerical value

The selection is done by positioning the cursor over the field to be modified. To change the type of measurement (metric, British or American, mass or volume) see functions POS "2.3" pag. 50, POS "2.20" pag. 50.

The value of Fs1-2 also depends on the value of the nominal diameter set by the function POS "2.10" pag. 50 .The following tables shown the units of measure available and the conversion factor by comparison with 1dm3 and 1kg. The converter accepts any kind of combination of units of measure satisfying both the following conditions:

- Numeric field value 99999
- 1/25 fsmax ≤ numeric field value ≤ fsmax.

Where fsmax is the maximum full scale value corresponding to the sensor, equal to a 10m/s liquid speed. The measure units are shown as appear on the display. The Imperial units units are diversified by using capital and small characters.

METRIC		
cm³	Cubic centimeter	
ml	Milliliter	
I	Liter	
dm³	Cubic decimeter	
dal	Decaliter	
hl	Hectoliter	
m³	Cubic meter	
ML	Mega Liter	

NON METRIC		
in³	Cubic inch	
Gal	American gallon	
GAL	Imperial gallon	
ft³	Cubic foot	
bbl	Standard barrel	
BBL	Oil barrel	
yd³	Cubic yard	
kgl	KAmerican Gallon	
KGL	K British Gallon	
IGL	Imperial Gallon	
IKG	Imperial K Gallon	
IGL	Acre foot	
MGL	Mega Gallon	
IMG	Imperial Mega Gallon	

MASS UNIT NOT METRIC	
Oz Ounce	
Lb	Pound
Ton	Short tons

MASS UNIT METRIC		
g	Gram	
Kg	Kilogram	
t	Ton	

When a measure mass unit is set, the specific gravity function is automatically enabled by the system. Please, note that the mass measure is heavily affected by the temperature. With certain liquids this may cause significant measurement errors. The following measure of time units can be selected: s = second, m = minute, h = hour, d = day.

#### NOTES FOR USING THE MCP INTERFACE

The command FRFS1 =? and command FRS2 = ?, edited by MCP software, return a list of only the unit compatible with the nominal diameter set. If the sensor is insertion type and the diameter is zero, the only possible unit is m/s if the flow rate were chosen metric units, else f/s for the unit of measurement non metric.



#### (POS.3.2-3.4) OutPut 1-2 Pulse Value

[Pls1-Pls2= dm3 x.xxxxx]

AL2

[OP1PV-OP2PV]

Vps1 and Vps2 is activated when the pulse values on channel 1 and 2 are set by the following functions POS "7.1" pag. 52; POS "7.4" pag. 52

This function allows the user to reset the generation of a pulse when a defined amount of liquid has passed through the sensor.

To set the parameter, complete the 2 fields, from left to right: 1) unit of measurement 2) numerical value and the selection is made by positioning the cursor in the field to be modified. To change the type of unit (metric, British or American, mass or volume) see the function POS "2.4" pag. 50; POS "2.5" pag. 50. The value Vps1 and Vps2 depends on the nominal diameter that can be set by the function POS "1.5" pag. 50 and the available units of measurement are those that can be set and described in the function POS "3.1" pag. 51.

#### (POS.3.3-3.5) OutPut 1-2 Pulse Time

[Tpls1-2= ms x.xxxxx]

AL2

[OP1PT-OP2PT]

Output 1 and output 2 pulse duration. Tmps1 and Tmps2 is activated when the pulse values on channel 1 and 2 are set by the following functions POS "7.1" pag. 52 and POS"7.4" pag. 52

. The user must set the corresponding duration of the pulse to be outputed. This value is expressed in milliseconds and has to be between 5 and 99 ms. When the high frequency output is present, then the minimum value can type of device is connected to the converter, the user must verify that the set pulse duration is compatible with the external device processing such pulses. If, for example, and electromechanical pulse counter is connected, a minimum pulse time of 5 milliseconds can be set.

**ATTENTION:** The converter can not detect problems that may occur; firstly, the pulse is too long the coils may burn out, secondly, if the pulse is too short, the counter may not be able to function, causing damage of the output.

(POS.3.6) ANalog Input 1 Scale

[AIN1]

AL6

[AIN1S]

Analog input 1 sensor's scale

(POS.3.7) ANalog Input 2 Scale

[AIN2]

AL6

[AIN2S]

Analog input 2 sensor's scale.

#### **MENU 4 MEASURE**

[Filt.bypass= ON/OFF]	AL3	[MFBYP]
	[Filt.bypass= ON/OFF]	[Filt.bypass= ON/OFF] AL3

This function modifies the standard behaviour of the filtering system. It can take the following values:

- □ "OFF": SMART adaptive filtering mode, with continuous measure evaluation analysis (default mode, standard use)
- "1": When the absolute value of the flow rate is greater than a minimum threshold (0.1 0.25% of 10 m/s f.s) the measure value is given without any filtering action. It permits to have the fastest possible response from the meter. Bypassing the filter implies that the obtained measure is more noisy than usual. This function may be useful for systems that needs to react to flow rate changes with the maximum speed and they don't care about unstable flow rate readings. Selecting an appropriate volume unit for pulses and totalizers (as big as possible) can minimize or even null the noise in long term evaluation.
- "2": The measure value is always filtered with the longest delay and strongest filtering action. It can be used when the level of native noise or instability on the measure is really high, preventing any smart filtering action. In this case the system will be really slow to react to flow step changes, but still capable of accurate readings.





#### (POS. 4.2) Measure Filter CUt-off Threshold

[Cut-off=XX.X%]

AL3

[MFCUT]

Setting the low flow cutoff threshold. This function is useful to avoid that flows close to zero, due to the electrical noises from tiny movements of liquid (due for example to vibrations of the pipe) which cause an increasing of the totalizers. The allowed range for this function is 0-25% of full scale set. For most applications a value between 0.5 and 1% is recommended.

#### (POS. 4.3) Auto Calibration Verify Enable

[Cal.verify=ON/OFF]

AL3

[ACAVE]

This function enables an automatic verification of board's coefficients. As the converter performs continuously a large number of tests, we recommend to use this function only in presence of wide range of temperature. Instead it is NOT recommended to use it when the instrument is used in metering applications (batch).

#### (POS. 4.4) High Immunity INPuts

[H.imm.inp.]

AL4

[HIINP]

The HIINP function (INPut High Immunity filter) introduces a hardware filter to be used ONLY IN CASE OF ABSOLUTE NECESSITY, when the measure is absolutely unstable or it is NOT possible to make the measure, and every possible attempt to reduce or eliminate the noise do not give a positive result, with particular attention of instrument ground connection. When this function is activated (HIINP = ON) the measure will be influenced by an unavoidable error estimated around 1%..

#### MENU 4 - MEASURE: ONLY MCP FUNCTIONS

Measure Sampling TiMe	[MCP ONLY]	AL4	[MSTME]

This function allows to program the sampling interval within these values:

0.'01(s)'|1.'02(s)'|2.'03(s)'|3.'04(s)'|4.'05(s)'|5.'06(s)'|6.'10(s)'|7.'12(s)'|8.'15(s)'|

default value=8:'15(s)'

#### Measure Filter Cut-off Threshold 2 [MCP ONLY] AL6 [MFCT2]

Setting the low flow cutoff threshold, it is similar to the function in 4.2. The value of this function is NOT visible on diplay but only with MCP command.

PRessure CUt-off Threshold	[MCP ONLY]	AL3	[PRCUT]
Pressure cut-off threshold			
Low Power cycle SIMulation	[LP Cycle sim.=ON/OFF]	AL6	[LPSIM]
Low power measurement cycle simulation.			

DYNamic Sample Analysis [MCP ONLY] AL6 [DYNSA]

Reserved to the service

DYNamic Sample Time [MCP ONLY] AL6 [DYNST]

Reserved to the service

DYNamic Range Threshold [MCP ONLY] AL6 [DYNRT]

Reserved to the service



#### **MENU 5 ALARMS**

#### (POS. 5.1) Flow Rate Alarm maX Positive

[Max+=XXXXX]

AL3

[FRAXP]

Maximum value alarm set for direct flow rate set. When the flow rate value exceeds such a threshold, then an alarm message is generated. The value of this parameter is expressed in technical units and can be set from 0 to frmax, with resolution 1/250 of frmax. Setting this parameter to OFF disables the alarm start.

#### (POS. 5.2) Flow Rate Alarm maX Negative

[Max-=XXXXXX

AL3

[FRAXN]

Maximum value alarm set for reverse flow rate set. When the flow rate value exceeds such a threshold, then an alarm message is generated. The value of this parameter is expressed in technical units and can be set from 0 to frmax, with resolution 1/250 of frmax. Setting this parameter to OFF disables the alarm start.

#### (POS. 5.3) Flow Rate Alarm miN Positive

[Min+=XXXXX]

AL3

[FRANP]

Minimum value alarm set for reverse flow rate set. When the flow rate value falls below such a threshold, then an alarm message is generated. The value of this parameter is expressed in technical units and can be set from 0 to frmax, with resolution 1/250 of frmax. Setting this parameter to OFF disables the alarm start.

#### (POS. 5.4) Flow Rate Alarm miN Negative

[Min-=XXXXX]

.3 [FRANN]

Minimum value alarm set for reverse flow rate set. When the flow rate value falls below such a threshold, then an alarm message is generated. The value of this parameter is expressed in technical units and can be set from 0 to frmax, with

#### (POS. 5.5) Alarm Thresholds HYSteresis

[Hysteresis=XXXXX]

AL3

[ATHYS]

Hysteresis threshold set for minimum and maximum flow rate alarms. The value of this parameter is expressed in technical units and can be set from 0 to 1/250 of the fsmax at 10 m / s..

#### GENERAL NOTE FOR ALARM THRESHOLDS (POS 5.5-5.6-5.7-5.8-5.9)

To set the alarm threshold the system calculates a technical units value using the data entered as an alarm value and as reference the full scale of the corresponding analog channel. If the calculated technical units value is close to zero, the function changes to the "OFF" value.

% Value set internally = (100 x value set on the display) / full scale value

resolution 1/250 of frmax. Setting this parameter to OFF disables the alarm start.

Therefore make sure that the value entered is sufficient not to fall back into the condition for which the function switches to the "OFF" value.

#### (POS. 5.6) Analog Input 1 alarm MaX

[A1Mx=XXXXXX]

AL3

[AI1MX]

MAX analog input 1 alarm threshold. Set this parameter to zero to disable the alarm start.

#### (POS. 5.7) Analog Input 1 alarm MiN

[A1Mn=XXXXXX]

AL3

[AI1MN]

Alarm threshold MIN analog input 1. Set this parameter to zero to disable the start of the alarm.

#### (POS. 5.8) Analog Input 1 HYsterisis

[In1H=xxx]

AL3

[HI1HY]

Analog Input 1 hysterisis value

#### (POS. 5.9) Analog Input 2 alarm MaX

[A2Mx=XXXXXX]

AL3

[AI2MX]

MAX alarm input analogue threshold 2. Set this parameter to zero to disable the start of the alarm.





IDOG	E 0	Anala	a Tanus	- 2 -1-	rm MiN
IPUS.	3.O	Anaio	u indul	. z ala	TITI IVIIIN

[A2Mx=XXXXXX]

AL3

[AI2MN]

Alarm threshold MIN analogue input 2. Set this parameter to zero to disable the start of the alarm.

(POS. 5.11) Analog Input 2 HYsterisis

Analog Input 2 hysterisis value

[In2H=xxx]

AL3

[HI2HY]

(POS. 5.10) ConFiguration Access Alarm Enable

[Cfg.ac.al= ON/OFF]

AL3

[CFAAE]

Configuration access alarm. Alarm used to protect the device from any tampering with hardware or access to the unauthorized system.

(POS. 5.11) Power Supply Loss Alarm Enable

[P.S. off. al = ON/OFF]

AL3

[PSLAE]

Power supply off state alarm. This function activates an alarm in the absence of mains power.



#### **MENU 6 INPUTS**

(POS. 6.1-2) Volume Totalizer Total/Partial Positive reset Enable

[T/P+/RESET=ON/OFF]

AL3

[VTTPE][VTPPE]

Enable positive totalizer count reset. When one of these functions is enabled (ON), the relative direct totalizer + can be reset through the input.

(POS. 6.3-4) Volume Totalizer Total/Partial Negative reset Enable

[T/P-/RESET=ON/OFF]

AL3

[VTTNE][VTPNE]

Enable positive totalizer count reset. When one of these functions is enabled (ON), the relative inverse totaliser - can be reset through the input.

(POS. 6.5) Totalizers Count Lock Input Enable

[Count lock= ON/OFF]

AL3

[TCLIE]

Totalizers counting lock command enable. When this function is active, applying a voltage on the on/off input terminals the system stops the totalizers no matter which is the flow rate.

(POS. 6.6) MeaSure Lock Input Enable

[Meas.lock=ON/OFF]

AL3

[MSLIE]

When this function is active (ON), applying a voltage on the on input terminals, the measurement is stopped, the meter will display zero flow.

(POS. 6.7) CALibration Input Enable

[Calibration=ON/OFF]

AL3

[CALIE]

When this function is active, applying a voltage on the on/off input terminals the meter performs a autozero calibration cycle. **ATTENTION:** If the voltage pulse is less than 1 sec., the meter performs a calibration cycle to compensate possible thermal drifts. If the voltage pulse is more 1 sec, the meter performs a zero calibration measure. To perform the calibration it is absolutely necessary for the sensor to be full of liquid and that the liquid is perfectly still. Even very small movement of the liquid may affect the result of the calibration, and, consequently, the accuracy of the system.

(POS. 6.8) SYStem Violation Detect

[sys.v.detect = ON/OFF]

AL3

[SYSVD]

Enable alarm related to system violation.

(POS. 6.9) Digital INput 2 Function

[D.In2=All./Vi.sist/OFF]

AL3

[DIN2F]

Input 2 function selection. The values that can be set are: system violation, flooding and OFF.

(POS. 6.10) Digital Input 3 Function

[D.In3=All./Vi.sist/OFF]

AL3

[DIN3F]

Input 3 function selection. The values that can be set are: system violation, flooding and OFF

(POS. 6.11) Digital INputs Power Supply

Digital auxiliary input power supply.

[D.in p.sup.=ON/OFF]

AL3

[DINPS]





#### **MENU 7 OUTPUTS**

Th	e values to he	associated with	outnute 1/2/3/4	relating to functions	271/7 <i>4</i> /7	7 7 / 7 10 are	listed helow:
- 1 1 1	e values to be	: associated with	- OULDUIS 1/2/3/4	Telauno lo lunctions	5 / . 1 / / .4 / /	.///.luale	listed below.

- □ OFF: DISABLE
- MAX AL. +: MAX DIRECT FLOW RATE OUTPUT (ENERGIZED = AL. OFF)
- ☐ MIN AL. +: MIN DIRECT FLOW RATE OUTPUT (ENERGIZED = AL. OFF)
- MAX/MIN+: MAX/MIN DIRECT FLOW RATE OUTPUT (ENERGIZED = AL. OFF)
- MAX AL.-: MAX INVERSE FLOW RATE OUTPUT (ENERGIZED = AL. OFF)
- MIN AL.-: MAX INVERSE FLOW RATE OUTPUT (ENERGIZED = AL. OFF)
- MAX/MIN-:MAX/MIN INVERSE FLOW RATE OUTPUT (ENERGIZED = AL. OFF)
- MAX/MIN+/-: MAX/MIN DIRECT FLOW RATE OUTPUT (ENERGIZED = AL. OFF)
- □ P.EMPTY: EMPTY PIPE ALLARM OUTPUT (ENERGIZED = AL. OFF)
- □ HARDW AL.SYSTEM ALARM: IT IS ACTIVATED WHEN ONE OR MORE OF THE FOLLOWING CONDITIONS OCCUR: coil excitation error, flow measurement acquisition error (critical signal or acquisition conditions), auxiliary measurement acquisition error. if they are installed (temperature, pressure, etc.)
- □ OVERFLOW: OUT OF RANGE ALLARM OUTPUT (ENERGIZED = FLOWRATE OK)
- ☐ ALL ALARMS: SUM OF ALL ALARMS POSSIBLE
- EXT. COMM: THE OUTPUT CAN ASSUME A STATUS DEPENDENT ON AN EXTERNAL COMMAND (via MCP, MODBUS, etc.)
- □ BATT. LOW: REPORT WHEN THE BATTERIES ARE ALMOST EMPTY
- □ FLOW RATE SIGN.: FLOW DIRECTION (ENERGIZED WHEN FLOW IS NEGATIVE)
- IAN1 MAX: MAXIMUM VALUE OF ANALOGUE INPUT 1 (function linked to the values set in the function "3.6" pag. 49)
- □ IAN1 MIN: MINIMUM VALUE OF ANALOGUE INPUT 1 (function linked to the values set in the function "3.6" pag. 51)
- □ IAN1 MX / MN: MAXIMUM AND MINIMUM VALUE OF ANALOGUE INPUT 1 (function linked to the values set in the function "3.6" pag. 51)
- AIN2 MAX: MAXIMUM VALUE OF ANALOGUE INPUT 2 (function linked to the values set in the function "3.7" pag. 51 )
- AIN2 MIN: MINIMUM VALUE OF ANALOGUE INPUT 2 (function linked to the values set in the function "3.7" pag. 51 )
- □ AIN2 MX / MN: MAXIMUM AND MINIMUM VALUE OF ANALOGUE INPUT 2 (function linked to the values set in the function "3.7" pag. 51 ))
- □ PULSES.+: PULSE POSITIVE FLOW RATE
- PULSES.-: PULSE NEGATIVE FLOW RATE
- □ PULSES+/-: PULSE NEGATIVE/POSITIVE FLOW RATE

#### (POS. 7.1) OUTput 1 Function

[Out1= XXXXX]

AL3

[OUT1F]

Assigned function output 1. The values that can be set are described in the introduction to the MENU 7 OUTPUTS description.

(POS. 7.2) OUtput 1 INVerted status

[Out1 inv.= OFF/ON]

AL3

[O1INV]

Output 1 Inverted status




(POS. 7.3) OUtput 1 PuLsed Status	[Out1 inv.= OFF/ON]	AL3	[O1PLS]
Output 1 PuLsed Status			
(POS. 7.4) OUTput 2 Function	[Out2= XXXXX]	AL3	[OUT2F]
Assigned function output 2. The values that can be description.	set are described in the introduction	on to the MENU 7	OUTPUTS
(POS. 7.5) OUtput 2 Inverted status	[Out2 inv.= OFF/ON]	AL3	[02INV]
OUtput 2 INVerted status.			
(POS. 7.6) OUtput 2 PuLsed Status	[Out2 pls.= OFF/ON]	AL3	[O2PLS]
Output 2 impulsive operation			
(POS. 7.7) OUTput 3 Function	[Out3= XXXXX]	AL3	[OUT3F]
Assigned function output 3. The values that can be description.	set are described in the introduction	on to the MENU 7	OUTPUTS
(POS. 7.8) OUtput 3 Inverted status	[Out3 inv.= OFF/ON]	AL3	[O3INV]
OUtput 3 INVerted status.			
(POS. 7.9) OUtput 3 PuLsed Status	[Out3 pls.= OFF/ON]	AL3	[O3PLS]
Output 3 impulsive operation			
(POS. 7.10) Output 4 Function	[Out4= XXXXX]	AL3	[OUT4F]
Assigned function output 4. The values that can be description.	set are described in the introduction	on to the MENU 7	OUTPUTS
(POS. 7.11) Output 4 Inverted status	[Out4 inv.= OFF/ON]	AL3	[04INV]
OUtput 4 Inverted status.			
(POS. 7.12) OUtput 4 PuLsed Status	[Out4 pls.= OFF/ON]	AL3	[O4PLS]
Output 4 impulsive operation			
(POS. 7.13) Analog Out. 1 ConFig.	[Out mA1= XXXXX]	AL3	[AO1CF]
Choice of the measuring range to be associated wit  ☐ Scale zero: 4 or 0mA	th the current output 1. There are t	three modification	fields:
☐ Full scale: 20 or 22mA			
☐ Field: + = positive, - = negative, blank = both, -0	0+ = central zero scale		



The values corresponding to the scale points are shown in the following chart:



CURRENT VALUES IN MA ASSOCIATE TO THE % FULL SCALE VALUE						
POSSIBLE FIELD	REVERSE FLOW VALUE		ZERO	DIREC	CT FLOW VALUE	
	≤-110%	-100%	0%	+100%	≥+110%	
Out.mA = 4 ÷ 20 +	4	4	4	20	20	
Out.mA = 4 ÷ 20 -	20	20	4	4	4	
Out.mA = 4 ÷ 20	20	20	4	20	20	
**Out.mA = 4 ÷ 20 –0+	4	4	12	20	20	



(POS. 7.14) Analog Output 1 Full Scale [A1S= xx/x x.xxxx] AL3 [AO1FS]

It allows to set the full scale value for analog output 1 independently from the main scale of the instrument.



## **MENU 8 COMMUNICATION**

For further information on the commands of the 8 communication menu, consult the MV255-3G-4G manual.

(POS. 8.1) communication process ABORT	[Comm.proc.abort]	AL3	[ABORT]
Immediate termination of the ongoing communication or	peration.		
(POS. 8.2) Send Status INFormation	[Send status]	AL3	[SSINF]
Sending information on the status of the device: with this e-mail address set containing the system status not as a			a FTP) to the
(POS. 8.3) Send Data Logger Fields Format	[Send DL format]	AL3	[SDLFF]
Sending format of process data fields collected in the data sent via FTP) containing as attachment a CSV file whose collected in the data logger will be formatted. Each field identifier that expresses the format of the numeric field. Examples:  RNUM = 5.0: number of records, data format = 5 into the numeric field.	se fields represent the format v can consist of a mnemonic co	vith which the proce	ss data `
□ DATE = yyyy / mm / dd: date expressed in year / md	onth / day		
☐ TIME = hh: mm: ss: time expressed in hours: minute	es: seconds		
☐ U = <measurement unit="">: unit of measurement used</measurement>	d		
☐ TOT_T + = 9.x: total positive totalizer value express	ed with numeric field up to 9 c	ligits, of which x dec	imals
For further details, a list of mnemonic codes can be four MV255 product.	nd in the manual relating to the	e 3G/4G communica	ation of the
(POS. 8.4) Send Sensor Test data Fields Format	[Send ST format]	AL3	[SSTFF]
Sending format fields of sensor analysis data collected i (or sent via FTP) containing a CSV file as an attachmen data relating to the sensor test system (BIV) collected in mnemonic code, the equal symbol and an identifier that Examples:  RNUM = 5.0: number of records, data format = 5 interests.	at whose fields represent the formatted log expresses the format of the n	ormat in which the a ger. Each field can o	nalysis
□ DATE = yyyy / mm / dd: date expressed in year / mo	onth / day		
☐ TIME = hh: mm: ss: time expressed in hours: minute	es: seconds		
☐ U = <measurement unit="">: unit of measurement used</measurement>	d		
□ ST_CODE = x4.0: code of the sensor test result, in			f the number

For further details, a list of mnemonic codes can be found in the manual relating to the 3G/4G communication of the MV255 product.

indicates hexadecimal format, 0 after the point indicates the number of decimal places, in this case zero)





(POS. 8.5) Send Instantaneous PRocess Data

[Send proc.data]

AL3

[SIPRD]

Send instant process data. With this command an e-mail message is sent (or sent via FTP) containing a CSV file with the process data measured as the message is sent as an attachment. The format of the data and the fields are the same as those used for the data logger.

(POS. 8.6) Send Last EVenTs

[Send events]

AL3

[SLEVT]

Sending last system events (MCP = SLEVT): with this command an e-mail message is sent (or sent via FTP) containing a text file (.TXT) with the list of system events as an attachment.

(POS. 8.7) Send ALaRMs [Send ALaRMs] AL3 [SALRM]

Sending alarm status (MCP = SALRM): with this command an e-mail message is sent (or sent via FTP) containing the alarm status as an attachment. The file format is described in the following example:

2018/06 / 06-18: 12: 00 ALARMS STATUS INTERVAL = 10m REL.TIME = 00: 10: 00

[AL.N.] [DESCRIPTION] [STATUS] [COUNT]

21 BATTERY 2 LOW OFF 1

In the first field there is the date and time. INTERVAL = xx specifies the time interval in which the system processes and examines the alarm situation. REL.TIME = hh: mm: ss indicates the time relative to the alarm analysis interval (this time goes from zero to the maximum value of the interval).

[AL.N.] indicates the alarm number

[DESCRIPTION] indicates a brief description of the alarm

[STATUS] indicates the current status of the alarm

[COUNT] indicates how many times that specific alarm has been activated and then deactivated in the alarm analysis time interval

#### (POS. 8.8) Send Last LOGged data

[Send I.data]

AL3

[SLLOG]

Send the process data present in the data logger. With this command an e-mail message is sent (or sent via FTP) containing as an attachment the last data collected by the data logger from the last request to send or from the start of the day (from 00:00:00).

#### (POS. 8.9) Send Last Sensor Test Data

[Send s.test]

AL3

[SLSTD]

Sending of sensor test analysis data (BIV). With this command an e-mail message is sent (or sent via FTP) containing as attachment the latest sensor test analysis data (BIV) from the last request to send or from the start of the day (from 00:00: 00).

### (POS. 8.10)Send Parameters ConFiGuration

[Send config.]

AL3

[SPCFG]

Sending configuration parameters. This command sends an e-mail message containing the list of instrument configuration parameters as an attachment.

## (POS. 8.11) Send FuNctions Enable Status

[Send fn.enable]

AL3

[SFNES]

Sending of the list of functions and of the relative enabling status for each of them. With this command an e-mail message is sent containing the list of instrument configuration functions and the enabling status of each of them as an attachment, or sent via FTP.



#### (POS. 8.12) Send Quick Start Functions List

[Send qs.list]

AL3

[SQSFL]

Sending the list of functions entered in the "quick start" menu. This command sends an e-mail message containing the list of functions included in the "quick start" menu as an attachment.

#### (POS. 8.13) Request RTC Synchronization

[RTC sync.req.]

AL3

[RRTCS]

Clock synchronization request. With this command MV 255 synchronizes its internal clock by connecting to the set time reference server.

(POS. 8.14) Check Mail BOX

[Check m.box]

AL3

[CMBOX]

Request to read new e-mail. With this command MV255 proceeds to search for new emails in the configured box.

#### (POS. 8.15) FTP DownLoad Command

FTP download1

AL3

[FTDLC]

FTP Download command. Request to read command file from the FTP server. This command makes a connection to the configured FTP server and the reading of the "MANIFEST.TXT" file.

(POS. 8.16) Mail SENd Enable

[Mail send]

AL3

[MSNDE]

General enabling of e-mail sending functions.

#### (POS. 8.17) Mail RECeive Enable

[Mail rec.]

AL3

[MRECE]

General enabling of email reception. This command enables the functions of receiving email.

#### (POS. 8.18) FTP UPload enable

[FTP upload]

AL3

[FTPUP]

Enabling of the data sending functions. This enables the sending of data (process, logger, events, etc.) from the client to the server.

## (POS. 8.19) FTP DowNload enable

[FTP download]

AL3

[FTPDN]

Enabling of data reception functions. This enables the reception of any commands or data files from the server to the client.

#### (POS. 8.20) ReMoTe operations ACcess level

[Rmt.op.acl]

AL6

[RMTAC]

Remote operating level access. The predisposition functions or the commands present in the body of the emails or in the attached files will be executed with the access level specified by the parameter MCP RMTAC. By default, the access level is 4. It is always possible to raise the access level for a command that you want to execute with greater relevance, or a group of commands, putting ACODE = xxxxxxxxx before the command you want to execute through the MCP interface.

#### (POS. 8.21) File CoMPression Enable

[File compr.]

AL3

[FCMPE]

Compression of attached files. This function allows the compression of all the attachments to be sent by e-mail, reducing dimensions and transmission times up to 1% of the original, or using a hundredth of the time and volume of the original data. Moreover this system allows the sending of several files within the same compressed archive, saving further connection time. The format used for compression has the extension ".ZIP".

### (POS. 8.22) Compressed File PaSsWord

[ZIP password]

AL3

[CFPSW]

Password protection for files sent in compressed format. When using compressed files, the archive created can be protected with a password. The same password must be entered when the archive is opened. In this way a further layer of data protection is realized.





#### (POS. 8.23) CoNnection TeSt Enable

[Conn.test]

AL3

[CNTSE]

Connection test. By activating this function, MV255 performs a test of the connection created to determine if all the necessary conditions are in place to guarantee the correct transit of the data. This function allows a considerable saving of time, energy and traffic as if the connection is not suitable, it is terminated and recreated within a few seconds, instead of starting transmission over an unstable connection that would result in long timeouts and retransmissions. In any case, this function does not guarantee the successful completion of all operations, but considerably reduces the possibility of connection failure.

## (POS. 8.24) Automatic EVents Send Enable

[Auto Ev.snd]

AL3

[AEVSE]

Automatic sending of events file in case of alarms. Activating this function, if during the process data sending interval of the data logger alarms or system errors have occurred, MV255 will automatically send the event file together with the data logger data.

## (POS. 8.25) Access Point NAMe

[Access p.name]

AL3

[APNAM]

Access Point Name, name of the access point on the network. It must be provided by the connection service provider.

#### (POS. 8.26) Access Point AUthentication Type

[Auth.type]

AL3

[APAUT]

Type of network access authentication: none, PAP or CHAP. It must comply with the requirements of the connection service provider.

#### (POS. 8.27) Access Point USeR

[User name]

AL3

[APUSR]

User name for network access: to be used if requested by the provider.

## (POS. 8.28) Access Point PaSsWord

[User password]

AL3

[APPSW]

Password for network access: to be used if requested by the provider

#### (POS. 8.29) Smtp service User NAMe

[SMTP User]

AL3

[SUNAM]

User name for authentication on remote server. This parameter is not necessary if MV255 is itself the mail server (direct sending to the recipient, not recommended).

## (POS. 8.30) Smtp service User PaSsWord

[SMTP psw.]

AL3

[SUPSW]

Password for authentication on remote server. This parameter is not necessary if MV255 is itself the mail server (direct sending to the recipient, not recommended).

## (POS. 8.31) Pop3 service User name

[POP3 User]

AL3

[PUNAM]

User name for authentication on the remote server.

### (POS. 8.32) Pop3 service User PaSsWord

[POP3 psw.]

AL3

[PUPSW]

Password for authentication on the remote server.

## (POS. 8.33) Ftp service User NAMe

[ FTP User]

AL3

[FUNAM]

User name for connection with FTP protocol.

## (POS. 8.34) Ftp service User PaSsWord

[FTP password]

AL3

[FUPSW]

Password for connection with FTP protocol.



## (POS. 8.35) Min.Antenna Signal Level thresh.Enable

[Min.sig.thr]

AL3

[MASLE]

Antenna signal level test. By setting this function to "ON", the instrument will start communication only if the signal received at the antenna is the minimum possible to guarantee a reliable connection. The level considered acceptable is the result of an elaboration that takes into account several parameters and network conditions, therefore this condition is of the ON / OFF type and cannot be modulated with a numerical value.

#### (POS. 8.36) Primary DNS Server

[Primary DNS]

AL3

[PDNSS]

IP address of the primary DNS server. If it is not specified (000.000.000.000) the system will use the one provided by the provider, otherwise it will use the one specified.

## (POS. 8.37) Secondary DNS Server

[Secondary DNS]

AL3

[SDNSS]

IP address of the secondary DNS server. If it is not specified (000.000.000.000) the system will use the one provided by the provider, otherwise it will use the one specified.

## (POS. 8.38) MAX number of ReTries

[Retries]

AL3

[MAXRT]

Maximum number of attempts for data transmission. Expected attempts from 1 to 9.

#### (POS. 8.39) INstrument IDentifier String

Instr.ID1

AL3

[INIDS]

Instrument identification string. This string appears along with the sender's name in the e-mail message and allows easy identification of the instrument that sent the message. The string is completed by the serial number of the card and is also shown in the body of the mail message with the item "Instrument ID:".

#### (POS. 8.40) HELO String

[HELO string]

AL3

[HELOS]

Client domain name (HELO string, MCP = HELOS). This parameter is necessary to specify the name of the domain to be submitted to the e-mail server during the connection. The name should be FQDN (fully qualified domain name), although it can almost never coincide with the real IP address because this is usually dynamically assigned for wireless networks. Maximum number of characters that can be entered is 32 including numbers and symbols.

## (POS. 8.41) EMail SeNDer address

[Sender addr.]

AL3

[EMSND]

Sender email address. Maximum number of characters that can be entered is 48 including numbers and symbols.

## (POS. 8.42) EMail REceiver address 1

[Receiver 1]

AL3

[EMRE1]

Recipient address 1 is mandatory and the maximum number of characters that can be entered is 48 including numbers and symbols.

### (POS. 8.43) EMail REceiver address 2

[Receiver 2]

AL3

[EMRE2]

Recipient address 2 is not mandatory and can be omitted or if set, it allows to send mail to a second recipient other than the recipient 1. The use of this second address for example can be to perform data back-up or control functions. The secondary address can only be set if a remote SMTP server is used and not if MV255 is the server itself. Maximum number of characters that can be entered is 48 including numbers and symbols.





#### (POS. 8.44) EMail SerVer Name

[SMTP server]

AL3

[EMSVN]

Name or address of the SMTP server that will send the mail. If you specify a FQDN (fully qualified domain name) in this field, MV255 will request the resolution of the name in IP address to the DNS servers set. If instead you set an IP address directly, you will avoid this step, but at the cost of less flexibility and adaptability of the system. For public servers like Google or Yahoo, the direct IP address is strongly discouraged and often doesn't work at all. If the server name or address is not set, MV255 will switch to stand-alone server mode, sending the mail directly to the recipient. Maximum number of characters that can be entered is 32 including numbers and symbols. The connection to the SMTP server must be checked and set according to the provider used.

### (POS. 8.45) Smtp Secure Connection MoDe

[SMTP sl]

AL3

[SSCMD]

Secure connection protocol SMTP (Simple Mail Transfer Protocol). This parameter must be set as required by the remote server. There are 3 possible ways: "OFF", unsecured connection (strongly discouraged); "IF AVAILABLE", (if available) if the remote server supports secure connection, this will be used, otherwise not (option mostly used, also by Google); "SSL / TLS", mandatory use of secure connection, if the remote server does not support it, the connection cannot be established.

### (POS. 8.46) EMail SerVer Port Number

[SMTP port]

AL3

[EMSVP]

Communication port. This parameter is mandatory and specifies the port number to be used for the connection. For unprotected connections or connections that can be protected at the server's discretion, the standard ports are 25 and 587 (rarely used). For connections that are protected at source (SSCMD = "SSL / TLS"), the standard port is 465. The system automatically sets the most correct port according to the type of connection desired, however it is always possible to change its value in case of different conditions.

## (POS. 8.47) POP3 SeRVer name

[POP3 server]

AL3

[P3SRV]

Server name or address. You can specify a fully qualified domain name (FQDN) or directly an IP address. Specifying an IP address directly saves a few hundred milliseconds of connection for the effective resolution of the name in the address, to the detriment of the flexibility of the system and with the risk of unstable or otherwise unsecured operation if public service providers were to be used. Maximum number of characters that can be entered is 32 including numbers and symbols.

#### (POS. 8.48) Pop3 Secure Connection MoDe

[POP3 sl]

AL3

[PSCMD]

Secure connection protocol for POP3. Three types of values can be specified: "OFF" (unprotected protocol, not recommended and now almost abandoned); "IF AVAILABLE", secure connection used if available; "SSL / TLS", mandatory secure connection (most common protocol, also used by Google).

#### (POS. 8.49) POP3 Server Port Number

[POP3 por

AL3

[P3SPN]

Connection port for receiving mail. The connection port is set automatically when you choose the secure connection method, however you can then change it if necessary. The standard values are "110" for unsafe connections and safe ones if available, while it is "995" for secure "SSL / TLS" connections.

## (POS. 8.50) FTP Server Name

[FTP server]

AL3

[FTPSN]

IP address or name of the FTP server. Maximum number of characters that can be entered is 32 including numbers and symbols.



#### (POS. 8.51) FTP SerVer Port number

[FTP port]

AL3

[FTPSP]

Server port number. The standard value is 21 but can be changed for greater security if you have complete control of the server.

(POS. 8.52) FTP server Secure connection Enable

[FTP sl]

AL3

[FTPSE]

Use of a secure connection using SSL. With this option the client will negotiate a secure connection with the server.

(POS. 8.53) FTp UPload Path

[FTP data]

AL3

[FTUPP]

Root directory of the FTP server where the data sent to the server will be stored. With this function it is possible to specify the name of the directory where the data sent by the meter will be stored.

(POS. 8.54) FTp UPload Events path

[FTP events]]

AL3

[FTUPE]

FTP server root directory where events and alarms generated by the meter will be stored.

(POS. 8.55) FTp DowNload Path

[FTP commands]

AL3

[FTDNP]

Root directory of the FTP server where the commands and firmware update files will be read.

(POS. 8.56) Secure Connection Server Certificate Check

[Cert.check]

AL3

[SCSCC]

Validate server certificate identity. When this parameter is active, in the case of a protected connection the meter checks that the identity provided by the server corresponds to that described in the certificate received. It is advisable to always leave this parameter active, as it is a guarantee that the server you are contacting is really the one requested.

(POS. 8.57) TiMe SeRVer name

[NTP server]

AL3

[TMSRV]

Server name or IP address for time and date synchronization. In this field you can specify the FQDN or IP address used to synchronize the time and date of the meter. For this parameter the same rules apply as for the servers related to sending and receiving electronic mail.

Notes on date and time synchronization:

Synchronization occurs simultaneously and simultaneously with the sending of the data logger process data and uses the standard NTP protocol on UDP port 123. Configure this service correctly using one of the many available providers.

(POS. 8.58) Data Send Time ReFerence

[T.ref]

AL3

[DSTRF]

Time reference for sending the process data collected in the data logger. This function allows the insertion of a date to be used as a time reference for sending data. The system will send all the data present in the data logger starting from the date entered. The date is updated each time the data is sent when the operation is successful (confirmation of receipt of the mail message by the server). If the transmission cannot take place after all the transmission attempts envisaged have been exhausted, the system abandons the session and tries again at the next scheduled time interval. The maximum time interval between the current date and the start date for sending data cannot exceed 8 days. Therefore, in the event of communications being restored following an interruption, it will be possible to receive the data of the last 8 days at the most.





## (POS. 8.59) MeSsages ChecK Time

[InMsTm]

AL3

[MSCKT]

Search interval for new messages. Specify the search interval for new messages with this function. When the specified time is reached, MV255 will exit the rest state and search for new messages. If e-mail is received, the latter will also be searched in addition to text messages. If the SMS management and the reception of e-mail messages are disabled, this function is no longer available on the menu.

## (POS. 8.60) PRocess Data Send Time

[ProcST]

AL3

[PRDST]

Interval for sending instant process data. Specify the interval for sending process data via e-mail with this function.

#### (POS. 8.61) LoGger Data Send Time

[LogDST]

AL3

[LGDST]

Interval for sending process data collected by the data logger. Specify the interval for sending the process data collected by the data logger via e-mail with this function.

## (POS. 8.62) Data Logger Send Complete File

[S.Compl.file]

AL3

[DLSCF]

Sending complete data logger files. By activating this function and preparing the sending of data every 24 hours, the data present in the data logger will only be sent completely on a daily basis (data collected from 00.00 to 23.59), regardless of the time chosen for sending. Obviously if there are still no complete data at the time of sending, this will not take place. Example: sending time 03.00: all the data collected the previous day will be sent from 00.00 to 23.59. It is enabled only if the function "8.61" pag. 53 is set to 24h.

## (POS. 8.63) ALarm Minimum Send Time

[Alarm time]

AL3

[ALMST]

Analysis interval and minimum time for sending alarms. This function specifies the time interval for analyzing the alarms and also the minimum time for sending. MV255 analyzes the status of the alarms in real time but to reduce the number of messages in the event of a very frequent repetitive situation, the messages are grouped and sent with a minimum guaranteed timing. When the first alarm occurs, MV255 will immediately send a signaling message. Subsequently, even if further alarms should occur, MV255 will analyze the situation but will not send further messages until the end of the specified minimum time interval. A new message will then be sent only if the alarm situation has changed during the analysis time interval.

## (POS. 8.64) SMS Functions Enable

[SMS f.en]

AL3

[SMSFE]

Global SMS management enablement. Enable this function to receive or send SMS.

### (POS. 8.65) Authorized INcoming Phone Number

[N.autor.]

AL3

[AINPN]

Number authorized to receive SMS. Set a number to be used as a filter key for SMS reception. The sender's number is compared with the key entered and consequently the receipt of the message can be authorized or refused. For example:

- ☐ AINPN = + 39: all numbers with the international prefix "+39" will be enabled for reception
- □ AINPN = + 39348: all numbers with the international prefix "+39" and the telephone prefix "348" will be enabled for reception
- □ AINPN = + 39348123: all numbers with the international prefix "+39", telephone operator prefix "348" starting with "123" will be enabled for reception.
- ☐ AINPN = + 393481234567: only one specific telephone number will be enabled for reception.
- ☐ AINPN =: all numbers are enabled for reception



#### (POS. 8.66) Short Message Send Destination 1

[Mess.recv.1]

AL3

[SMSD1]

Destination of messages 1. Destination 1 receives any message generated by the system. Maximum number of characters that can be entered is 20 including numbers and symbols.

#### (POS. 8.67) Short Message Send Destination 2

[Mess.recv.2]

AL3

[SMSD2]

Destination of messages 2. The destination 2 receives only the alarm relating to the flooding of the installation (it is activated if enabled, see the alarm menu). Maximum number of characters that can be entered is 20 including numbers and symbols.

#### (POS. 8.68) Short Message Send Destination 3

[Mess.recv.3]

AL3

[SMSD3]

Destination of messages 3. Destination 3 only receives the alarm relating to tampering with the installation (it is activated if enabled, see alarm menu). Maximum number of characters that can be entered is 20 including numbers and symbols.

#### MENU 8 - COMMUNICATION: ONLY MCP FUNCTIONS

#### Send Expressly Requested FiLe

[MCP ONLY]

AL3

[SERFL]

Sending a specific file. With this function it is possible to specify a file that you want to receive from MV255. This file will be sent as an e-mail attachment or sent via FTP.

Usage: SERFL = <file name>. The file name must be indicated complete with the path, as in the following example: SERFL yyyy = \ MM \ gg \ EVENTS.TXT

FallBack 2G Enable [MCP ONLY] AL4 [FB2GE]

The FB2GE (FallBack to 2G Enable) function is used to enable the 2G band on the 3G/4G modem when the 3G/4G signal is not available. By default the 2G band is deactivated on the 3G/4G modem. Switching to the 2G network is to be understood as a last resort in case of poor or no connection and where 3G/4G is not available.

ATTENTION: the 2G radio band can consume up to 5 TIMES the energy needed for 3G/4G, furthermore, given the limited transmission capacity, the time required to send data can be considerably increased, with additional energy consumption.

#### ML255 ComPatibility Enable

[MCP ONLY]

AL4

[MLCPE]

Compatible data formatting for ML series converters.





# **MENU 9 DISPLAY**

(POS. 9.1) Layout LANGuage	[Language]	AL1	[LLANG]
Choice of the language. There are 8 languages available: GE German, FR = French, PT = Portuguese, ES = Spanish.	3 = English, IT = Italian, TR :	= Turkish, PL = Polish	DE =
(POS. 9.2) KeyBoard TiMeout Time	[Disp.time]	AL1	[KBTMT]
This function set dispay/keyboard inactivity. The set values a	re from 020 to 255 second.		
(POS. 9.3) DISplay Refresh Frequency	[F.Display]	AL2	[DISRF]
Visualizzazione frequenza aggiornamento			
(POS. 9.4) DISplay Function Number	[Disp.fn.]	AL2	[DISFN]
This function sets the display of the page making it visible whas sociated with a number that corresponds to the position.	nen you start the display. Fo	r each display page is	
(POS. 9.5) Display function LOcK Enable	[Disp.lock]	AL2	[DLOKE]
This function blocks the scrolling of the pages displayed and	selected by the function PO	S "9.3" pag. 54.	
(POS. 9.6) Partial TOTalizers Enable	[Part.tot.]	AL2	[PTOTE]
This function enables the display of partial totalizer in visualizer	zation pages.		
(POS. 9.7) NEGative value Totalizers Enable	[Neg.tot.]	AL2	[NEGTE]
This function enables the display of negative totalizer in visua	alization pages.		
(POS. 9.8) Net Value ToTalizers Enable	[Net tot.]	AL2	[NVTTE]
This function enables the display of net totalizer in visualization	on pages.		
(POS. 9.9) Date And Time Display Enable	[Disp.date]	AL2	[DATDE]
This function enables the display of date and time in visualization	ation pages.		
(POS. 9.10) Quick STart Menu Enable	[Quick start]	AL2	[QSTME]

This function enables the quick start menu.



## **MENU 10 DATA LOGGER**

(POS. 10.1) Data LOGger Enable [D.logger en.=ON/OFF] AL3 [DLOGE]

This function enables data loger.

## The following functions are activated by [D.loger en= ON]

(POS. 10.2) Data Logger Units of Measure Enable	[Meas.units= ON]	AL3	[DLUME]
Enables the registration of the units of measurement set in the o	device.		
(POS. 10.3) Data Logger Field Separator Character	[Field separ.= , ;]	AL3	[DLFSC]
This function sets the separation character between the recorde	ed data.		
(POS. 10.4) Data Logger Decimal Separator Character	[Decim.separ.= .]	AL3	[DLDSC]
This function sets the separator character between the value of	the num. value of the recorded o	lata.	
(POS. 10.5) Data LoGger Sample Interval	[Interv.= xx:xx:xx]	AL3	[DLGSI]
This function sets the data logging frequency. [interval = Hours:	Minutes: seconds]		
(POS. 10.6) Data logger Totalizer Total Positive Enable	[Log T+= ON]	AL3	[DTTPE]
Enables recording of total positive totalizer values.			
(POS. 10.7) Data logger Totalizer Partial Positive Enable	[Log P+= ON]	AL3	[DTPPE]
Enables recording of positive partial totalizer values.			
(POS. 10.8) Data logger Totalizer Total Negative Enable	[Log T-= ON]	AL3	[DTTNE]
Enables recording of total negative totalizer values.			
(POS. 10.9) Data logger Totalizer Partial Negative Enable	[Log P-= ON]	AL3	[DTPNE]
Enables recording of negative partial totalizer values.			
(POS. 10.10) Data Logger totalizer Total Net Enable	[Log TN= ON]	AL3	[DLTNE]
Enables recording of total totalizer net values.			
(POS. 10.11) Data Logger totalizer Partial Net Enable	[Log PN= ON]	AL3	[DLPNE]
Enables the recording of the net partial totalizer values.			
(POS. 10.12) Data logger Flow rate in Technical Units Enable	[Log Q(UM)= ON]	AL3	[DFTUE]
Ability to record the flow rate in a set unit of measurement.			
(POS. 10.13) Data logger Flow rate in PerCentage Enable	[Log Q(%)= ON]	AL3	[DFPCE]
Ability to record the flow rate as a percentage of the set full scale	e value		
(POS. 10.14) Data logger ALarm Events Enable	[Log AL.EV= ON]	AL3	[DALEE]
Enables recording of events and alarms.			
(POS. 10.15) Data logger ADditional Measures Enable	[Log ADM= ON]	AL6	[DADME]

It allows to log the additional analog measurements, as for example pressure and temperature.

This option is valid only with analog inputs enabled and the module installed.





(POS. 10.16) Data logger Sensor Test Results Enable	[Log STR= ON]	AL6	[DSTRE]
Enable logging of sensor test results.			
(POS. 10.17) Data logger Board TemperatureS Enable	[Log BTS= ON]	AL6	[DBTSE]
Enable logging of board temperature.			
(POS. 10.18) Data logger Internal Board Voltages	[Log IBV= ON]	AL6	[DIBVE]
Enable logging of internal board voltage.			
(POS. 10.19) Data logger Electrodes DC Voltages Enable	[Log EDC= ON]	AL6	[DEDVE]
Enable logging of electrodes DC voltage.			
(POS. 10.20) Data logger Electrodes AC voltages Enable	[Log AEC= ON]	AL6	[DEAVE]
Enable logging of electrodes AC voltage.			
(POS. 10.21) Data logger Electrodes Source Impedance Enable	[Log EIZ= ON]	AL6	[DESIE]
Enable logging of electrodes impedance.			
(POS. 10.22) Data logger Sensor Coils Values Enable	[Log SCV= ON]	AL6	[DSCVE]
Enable logging of sensor coils value.			

## **MENU 10 - DATA LOGGER: ONLY MCP FUNCTIONS**

LoG All Information Enable	[MCP ONLY]	AL6	[LGAIE]

Enable logging of all instrument events. This function enables the recording of all data for which registration is required. Activating this function, the system records in detail each operation with the consequence that the file produced by the logger will be large and will incisively reduce the space in the SD memory. It is advisable to activate this function only if necessary (for example to identify communication problems with SMTP or FTP servers).

Data Logger FieLds Format	[MCP ONLY]	AL0	[DLFLF]
Data logger fields format			
Sensor Test data Fields Format	[MCP ONLY]	AL0	[STFLF]
Format sensor test data fields			
Data Logger Instantaneous Process Data	[MCP ONLY]	AL0	[DLIPD]


Read instantaneous values of process data.



## DATA MANAGEMENT MEASURES AND EVENTS

The data collected by the data logger are stored on a micro SD card. Their organization is based on a tree structure and the system saves day by day, in two separate files, events and data loggers. Data can be downloaded via the MCP interface or via mail and / or FTP protocol.

**Note:** The number of processed data depends on the sampling interval set and the number of variables enabled for registration.






refers to the CREATION date of the file




## **USING DATA LOGGER BY MCP INTERFACE**

The data collected by the data logger are stored on a micro SD card. Their organization is based on a tree structure and the system saves day by day, in two separate files, events and data loggers. Data can be downloaded via the MCP interface, as shown in the following examples. **Note:** The number of processed data depends on the sampling interval set and the number of variables enabled for registration.

## MCP INTERFACE



Select the "data logger" tab as shown below to access the file download interface.



## A=Data source

- □ Events: Download system events (Sample Line 2016/09 / 14-01: 00: 00.000 -W0216- [1] ALARMS still active)
- Data logger: Download and save the recorded data through the data logger function.
- ☐ Sensor Verify: Download sensor verification data (if BIV is active).
- ☐ Generic file: Download a specific file contained in the SD card.



#### B=When

Indicates the reference period to download the data.

- ☐ Today: current day file download
- Data range: selection of the download period.

## C=Today

(divides today's day into different download frames)

- ☐ Last: download only the latest data collected AFTER the last data download
- ☐ All: download the data of the whole current day of the file

## D=Save path:

☐ This option allows you to save the files in the desired folder on your PC


#### E=Download:

■ Button to start the download process

#### F=Stop:

■ Button to stop the download process

## **Example: Download Events**



To download all the events of the current day in a specific folder, set the below parameters as follows:

Data source: Events When: Today Today: All Save path: C: / .....

The parameters are set then click the Download button.

Once the download is completed, a window containing the list of today's events appears. The file is saved in the specified folder in .txt format .





**Note:** The fields are at a fixed position, regardless of whether the previous fields are active or not. Inactive fields are empty (delimited by the separator but do not contain data).

4	N° RECORDS n° n°	N°NUM: record number. Display progressively the number of records recorded.	
Ω	DATE dd/mm/yy dd/mm/yy	DATE: Display of the recording date for each record.	
ပ	HOUR 00:00:00 00:00:00	TIME: Displaying the recording time for each record.	
Е	T+ UM 0 dm³ 0 dm³	Total positive totalizer value: Form Fields when the send flag is active on the totalizer T+.	
ъ П	P+ UM 0 dm³ 0 dm³ 0 dm³	Partial positive totalizer value: Form Fields when the send flag is active on the totalizer P+.	
<b>エ</b>	T- UM 0 dm³ 0 dm³	Total negative totalizer value: Form Fields when the send flag is active on the totalizer T	
~ ×	P- UM 0 dm <sup>3</sup> 0 dm <sup>3</sup>	Partial negative totalizer value: Form Fields when the send flag is active on the totalizer P	
_ N	O dm <sup>3</sup>	Total net totalizer value: Form Fields when the send flag is active on the totalizer TN.	
z	O dm <sup>3</sup>	Partial net totalizer value: Form Fields when the send flag is active on the totalizer PN	
<b>_</b>	dm3/s dm3/s dm3/s	Flow rate: Form Fields present when the send flag is on the flow in units of measurement.	
Ø	F. RATE 0 0		
~	× Value % % %	Flow rate %: value of the flow expressed in percent of the full scale.  Fields present when the percentage flow send flag is active.	
S	F.RATE 0 0	Ticids present when the percentage now send hag is active.	
<b>—</b>	ALARMS AL AL AL		
n	N° ALARMS 0 (0x000000000000001) 4 (0x0000000001430080) 5 (0x000000001430080)	<b>ALARMS:</b> value of the number of active alarms. Fields present when the alarm sending flag is active (only N. of total alarms present).	
>	N A E E	Loss of current measured during insulation test: available value when recording the sensor test	
>	CPTI	data is active.	
×	T.RISEA UM 0 ms 0 ms	Time rise A: Available value when recording the sensor test data is active.	



Z	ms ms ms				
A	T. RISE B 0 0	Time rise B: Available value when recording the sensor test data is active.			
AB	ERROR ERR ERR ERR	Sensor test error code: Available value when recording the sensor test data is active.			
AC	° 0 0 0				
AD	> > > ∑	Voltage measured on electrode E1: Form fields when is active the recording of data on the input			
AE	0 0 0	voltage (diagnostic value).			
AF	∑. > > >	oltage measured on electrode E2: Form fields when is active the recording of data on the input			
AG	E2V 0.023 0.023 0.023	voltage (diagnostic value).			
AH	> > > ∑	Differential voltage between the two electrodes VD=E1-E2:			
₹	Value 0 0	Form fields when is active the recording of data on the input voltage (diagnostic value)			
A	> > >	Common mode voltage in the electrodes VC=E1+E2/2:			
AK	Value 0 0	Form fields when is active the recording of data on the input voltage (diagnostic value).			
AL	> > >	Noise at low frequency measured on the electrodes:			
MA	Value 0 0	Form fields when is active the recording of data on the input signal noise levels (diagnostic value).			
A	> > >	Differential low frequency noise measured on the electrodes:			
AO	Value 0 0	Form fields when is active the recording of data on the input signal noise levels (diagnostic values).			
AP	M. J.	Low-frequency noise measured input ADC:			
AQ	Value 0 0 0	Form fields when is active the recording of data on the input signal noise levels (diagnostic values).			
AR	M.U. m. m. v. v. m. v. v. m. v.	High frequency noise measured input ADC:			
AS	Value 0 0	Form fields when is active the recording of data on the input signal noise levels (diagnostic values).			
AT	U.M kohm kohm	Measured equivalent resistance on the electrode 1:			
AU	E1R 0 0	Form fields when is active the recording of data on the electrode resistance measurements (diagnostic values).			
A	U.M kohm kohm	Measured equivalent resistance on the electrode 2:  Form fields when is active the recording of data on the electrode resistance measurements (diagnostic			
<b>AM</b>	E2R 0 0	values).			
AX	U.M Am m Am Am	Coils excitation current:			
ΑΥ	EXC.CURR. 0 0	Form fields when is active the recording of data related to the sensor excitation circuit measures (diagnostic value)			
AZ	Ohm Ohm	Measured resistance of the excitation circuit (coil + cable):			
ВА	R.COILS 0 0	Form fields when is active the recording of data relative to the sensor excitation circuit measures (diagnostic values).			






BB	————————————————————————————————————	Temperature measured on the sensor coils (indirect measurement): Form fields when the data		
BC	T.COILS 0 0	transmission flag is active relative to the sensor excitation circuit measures (diagnostic values).		
BD	KPa KPa KPa			
BE	N 0 0 0	A_IN1: value of analog input 1.		
BF	Z X X X X X X X X X X X X X X X X X X X			
BG	0 0 0 0 0 0	A_IN2: value of analog input 2		
ВН	N 0 0 0	CPU temperature: Form fields when the data on the card's internal power supply voltage		
B	1CPU 0 0	measurements flag is ON (diagnostic value).		
B	돌 > > >	Net eveleble value		
BK	5000	Not avaiable value		
BL	> > >	Positive supply voltage of analog circuits: Form fields when the data on the card's internal power		
BM	Value 0 0 0	supply voltage measurements flag is ON (diagnostic values).		
BN		<b>Negative supply voltage of the analog circuits:</b> Form fields when the data on the card's internal power supply voltage measurements flag is ON (diagnostic values).		
BO	Value 0 0			
ВР	Σ. , , ,			
BQ	M. 0	Not avaiable value		
BR	D , , ,	Not avaiable value		
BS	Σ 0 0 0			
BT	₹ > > >			
BU	Value 0 0	Unit of measurement (V) and battery voltage value		
MS ≥	Value %	9/ Rattory charge: Form fields when the data on the card's internal newer supply voltage		
BW	BATT % 0 0	<b>% Battery charge:</b> Form fields when the data on the card's internal power supply voltage measurements flag is ON (diagnostic values).		
BX	HEX 0x8A97 0xD1D8 0x3754	Checksum		



## **Example: Download Data Logger**


Note: it is recommended the date synchronization between converter and PC to perform correctly the events and logger reading operations.



The following is the formatting of the data of the files downloaded from the download data logger setting in a file in .CSV format. The access level to download this type of file is the 5th diagnostic level..

### **Example: Sensor Verify**

To make the control measures of the state of the sensor and the related automatic verification files is necessary that the BIV function (Built-In-Verificator) is turned on (optional). If the BIV is enabled, the instrument automatically tests the sensor operating parameters every hour and records the data on the "STESTLOG.CSV" file; it is possible to do a manual check using the "sens.verify" command on the "Diagnostic" menu or through the MCP "SVERC" command






89 di 122



## Example download generic file



This function allows to select a file in the SD memory and download it. In the "Generic file path" specify the file name contained in the SD and indicate "Save path" where to save the file. Set these values to proceed with the download by clicking the "download".



## **MENU 11 - FUNCTION**

The following functions are activated by first pressing the "ENTER" and then the "ESC" when the screen appears "confirm" to start the function.

committee of the function.			
(POS. 11.1) Volume Totalizer Total Positive Reset	[T+ RESET]	AL3	[VTTPR]
Reset total direct totalizer for direct flow rate			
(POS. 11.2) Volume Totalizer Partial Positive Reset	[P+ RESET]	AL3	[VTPPR]
Reset total partial totalizer for direct flow rate			
(POS. 11.3) Volume Totalizer Total Negative Reset	[T- RESET]	AL3	[VTTNR]
Reset total reverse totalizer for direct flow rate.			
(POS. 11.4) Volume Totalizer Partial Negative Reset	[P- RESET]	AL3	[VTPNR]
Reset partial reverse totalizer for direct flow rate			
(POS. 11.5) Load Factory Default Sensor Data	[Load sens.f.def]	AL3	[LFDSD]
This function loads the factory data of the sensor. To save the	ne factory data see function	(11.7).	
(POS. 11.6) Load Factory Default Converter Data	[Load conv.f.def]	AL3	[LFDCD]
This function loads the factory data of the converter. To save	e the data, see function (11.8	3).	
(POS. 11.7) Save Factory Default Sensor Data	[Save sens.f.def]	AL6	[SFDSD]
This function saves the factory data of the sensor.			
(POS. 11.8) Save Factory Default Converter Data	[Save conv.f.def]	AL6	[SFDCD]
This function saves the factory data of the converter.			
(POS. 11.9) CALibration Immediate Command	[Calibration]	AL5	[CALIC]
Activation of the function adjusts the board calibration parandisplayed will display the message: "Execute?" Press and he	•		

Activation of the function adjusts the board calibration parameters. Pressing the ENTER key briefly while the function is displayed will display the message: "Execute?" Press and hold the Enter key to proceed. Press any other key to cancel the operation. NOTE: If a valid sensor data table is present, the calibration starts automatically even when one of the following parameters is modified:

SENSOR DIAMETER -> Menu Sensor1 / SENSOR MODEL -> Menu Sensor1

S. FREQ. -> Menu Sensor1 / EXC CURRENT -> Menu Sensor1

To check the calibration status, active or inactive, enter the command MCP "CALIC?" And check as follows: CALIC = 1 calibration in progress / CALIC = 0 calibration completed

## **MENU 11 - FUNCTION: ONLY MCP FUNCTIONS**

Save sensor reference data	[MCP ONLY]	AL4	[SRFDS]
Save conv.f.def= ON, saving sensor reference data.			

Cave conv.n.der Ott, saving sensor reference date

Used for the function "meter data" pag. 106.

Input ReFerence Data Save [MCP ONLY] AL4 [IRFDS]

Save el.input reference data





## **MENU 12 - DIAGNOSTIC**

#### (POS. 12.1) AutoTeSt Immediate Command

[Self test]

AL3

[ATSIC]

Self-test function. This function stops the normal functions of the counter and performs a complete test cycle on the input, measurement and excitation circuits. To Activate this function, after having selected it, press the "enter" button and the question "Confirm?" Press "ESC" to automatically start the test or any other button to cancel the operation. At the end of the operation the converter restarts and restores the screen to the initial display page. This function is performed automatically when the device is turned on.

(POS. 12.2) Test display [Test display] AL1 NO MCP COMMAND

This function allows you to test the graphic display of the converter. During the execution of this function, 4 screens are displayed in sequence to test the correct operation of the device.

## (POS. 12.3) Sensor VERify Command

[ Sens. verify ]

AL3

[SVERC]

Diagnostic function and sensor verification, allows to do a sensor test (if BIV enabled).

#### (POS. 12.4) Measure SIMulation ENable

[Flow sim=ON]

\L3

[MSIEN]

Enabling the flow simulation function. By activating this function it is possible to simulate a flow. With this system it is possible to test the outputs of the meter and the instruments connected to it. After enabling the flow rate, this symbol appears on the display and the simulation can be:

- □ Set: pressing the "Enter" key from one of the display pages, to set the% flow rate value, and pressing "Enter" again to confirm the value.
- ☐ Ended: by pressing the "Esc" key on the page where the simulated value is set.

## (POS. 12.5) Diagnostic System ValueS

[Val.diag.sist.]

AL5

[DSVLS]

This function shows the values of CPU temperatures and total measure cycle


#### (POS. 12.6) Diagnostic Measure ValueS

[Display measures]

AL5

[DMVLS]

This function shows the values of various internal parameters (diagnostic purpose reserved for the service).





(POS. 12.7) Diagnostic Communication Value.	(POS. 12.	) Diagnostic	Communication	VaLue:
---	-----------	--------------	---------------	--------

[Val.diag.comm.]

AL5

[DCVLS]

This function shows the values of various internal specific communication parameters (diagnostic purpose reserved for the service).

PPP1_STATUS:	NETW DEAD	E_TSPLAYR: E_PPPFRM1:	0
MCPI_S:	ESTABLISH	E_IP_HDR1:	0
R×CNT:	_50906397	E_IP_HDR2:	Ø
TxCNT:	799361398	E_IP_HDR3:	Ø
RETRANSM.:	@	E_IP_HDR4:	Ø
BROADCAST:	68 <u>0</u>	E_IP_HDB5:	Ø
E_SR_LINK:	ø	E_IP_HDR6:	Ø
E_BFOVERR:	9	E_IP_HDB7:	Ø
E_TSPLAYR:	9	E_IP_HDB9:	Ø
E_PPPFRM1:	9	E_TCPHDR1:	9
$\mathbf{E}_{\perp}\mathbf{I}\mathbf{P}_{\perp}\mathbf{H}\mathbf{D}\mathbf{R}1:$	9	E_TCPHDR2:	Ø
E_IP_HDR2:	Ø	E_UDPHDR1:	Ø
E_IP_HDR3:	9	E_UDPHDR2:	Ø
E_IP_HDR4:	ø	E_UDPHDR3:	Ø
E_IP_HDR5:	9	E_ICMPHDR:	Ø

The following are the statuses for the PPP and MCPI link for the device connection.

### Status of the PPP link:

- □ "UNDT" = undetermined.
- □ "DEAD" = PPP link not active.
- ☐ "LCP" = phase of LCP, transition phase.
- ☐ "AUTH" = transition phase.
- ☐ "IPCP" = IP address assignment.
- "NETW" = established network (normal persistent condition when the connection is active).
- "TERM" = termination request, transition phase.

## MCPI link status:

- □ "CLOSED" = closed socket
- ☐ "ACCEPT" = Waiting for new connection
- ☐ "ESTABLISH" = established link
- ☐ "CLS\_WAIT" = waiting for closure
- □ "LAST\_ACK" = LASK ACK sent
- □ "FIN\_WAIT" = (See the RFC TCP / IP documentation)
- □ "TIME\_WAIT" = (See the RFC TCP / IP documentation)





#### (POS. 12.8) Short Message Test

[SMS test]

AL3

[SMSTS]

Test sending SMS to all recipients (Autotest Immediate Command). This function allows for each set of SMS recipients to send a test message containing the model and software version installed on the device. (the same string that is received with the function POS "12.13" pag. 55 ). This is also a way to also know the telephone number that the wireless operator has assigned to the SIM card mounted on MV255.

#### (POS. 12.9) SMtP Connection Test

[SMTP conn test]

AL3

[SMPCT]

Test SMTP connection. With this function it is possible to make a test connection to the SMTP server used for sending e-mail. The test does not send any messages and is limited to verifying that the server, the port, the username and the password set are all correct.

#### (POS. 12.10) POP3 Connection Test

[POP3 conn.test]

AL3

[POPCT]

POP3 connection test. With this function it is possible to check whether the parameters entered as server name, server port, user name and password are correct. The test does not download any messages from the POP3 server.

### (POS. 12.11) FTP Connection Test

[FTP conn.test]

AL3

[FTPCT]

FTP connection test (MCP FTPCT). With this function it is possible to check whether the parameters entered as server name, server port, user name and password are correct. The test does not transfer data.

#### (POS. 12.12) Oscilloscope function


[Display graphs]

AL5

[OSCOP]

This function displays the input graphs. The MCP command allows you to see the data on the graph in numeric format, as a list of values. Typing OSCOP = 1 allows you to view the numeric values of the graph in position 1. The measurement charts provided are 8.

- Z=impedance
- ☐ C. current=Coils current
- C. volt=Coils voltage
- C.load: Coils load
- ☐ Input 1= E1
- ☐ Input 2=E2
- □ SIGNAL=analog to digital converter.
- ☐ Input 1-Input 2






[SD card info]


AL<sub>0</sub>

[SDSTA]

This function indicates the status of the SD card as shown in the following figure.



The statistical calculation is performed whenever the SDSTA command is invoked or when accessed from the display. The statistical data is updated AUTOMATICALLY every day (24 hours) or manually each time the function is called up on the display or the SDSTA command is sent. However, since a minimum time of one hour is required for detection, the data will not be recalculated before this time interval.



Minimum time of 1 hour for the new data update

The SD card must be replaced only by the service. The use of commercial cards could disable some functionality of the instrument.

(POS. 12.14) Model and software version

[Firmware info]

AL0

[MODSV]

Version / revision firmware information.

00.0000.FFFF | 00.000 00:00:00

(POS. 12.15) Serial number	[S/N=XXXXXX]	AL0	[SRNUM]

Displays the serial number of the instrument board. (read only)

(POS. 12.16) Total working time AL<sub>0</sub> [TWKTM] [WT = xxxx: xx: xx: xx]

View Total working time instrument. (read only)

(POS. 12.17) Total measure cycles [TC= xxxxxxxxxxx] AL<sub>0</sub> [TMCYC]

Total number of cycles measured on battery. (read only)

## MENU 12 DIAGNOSTIC: ONLY MCP FUNCTIONS

Diagnostic function	[MCP ONLY]	AL6	[DIAGF]
Diagnostic functions code.			
Coil current mean real value	[MCP ONLY]	AL6	[CCMRV]
Real average excitation current value.			
Analog input 1 Start Scale Cal.	[MCP ONLY]	AL6	[A1SSC]
Calibration of the analog input 1 start scale.			

[MCP ONLY] Analog input 1 Full Scale Cal. AL<sub>6</sub> [A1FSC]

End of scale analogue input calibration 1.





Analog input 2 Start Scale Cal. [MCP ONLY] AL6 [A2SSC]

Calibration of the analog input 2 start scale.

Analog input 2 Full Scale Cal. [MCP ONLY] AL6 [A2FSC]

End of scale analogue input calibration 2

## **MENU 13 - SYSTEM**

(POS. 13.1) Daylight Saving Time Enable [Dayl.saving = ON/OFF] AL2 [DYSTE]

Daylight saving time change.

(POS. 13.2) Time zone [Time zone h+xx.xx] AL2 [TZONE]

Set the difference between GMT and the local time where the instrument is installed. Set the time zone before the system date and time setting as this function, if set after the system date and time, will in turn change the newly set date and time.

(POS. 13.3) Date and Time [xxxx/xx/xx-xx:xx] AL2 [DTIME]

Setting the system date and time.

(POS. 13.4) Access level n°1 code [L1 code] AL1 [L1ACD]

This function enables or disables the functions of the main menu for each access level code. Each level unlocks the functionality of the lower level if the function is enabled POS "13.10" pag. 55.

(POS. 13.5) Access level n°2 code [L2 code] AL2 [L2ACD]

This function enables or disables the functions of the main menu for each access level code. Each level unlocks the functionality of the lower level if the function is enabled OS "13.10" pag. 55.

(POS. 13.6) Access level n°3 code [L3 code] AL3 [L3ACD]

This function enables or disables the functions of the main menu for each access level code. Each level unlocks the functionality of the lower level if the function is enabled POS "13.10" pag. 55.

(POS. 13.7) Access level n°4 code [L4 code] AL4 [L4ACD]

This function enables or disables the functions of the main menu for each access level code. Each level unlocks the functionality of the lower level if the function is enabled POS "13.10" pag. 55.

(POS. 13.8) Access level n°5 code [L5 code] AL5 [L5ACD]

This function enables or disables the functions of the main menu for each access level code. Each level unlocks the functionality of the lower level if the function is enabled POS "13.10" pag. 55.

(POS. 13.9) Access level n°6 code [L6 code] AL6 [L6ACD]

This function enables or disables the functions of the main menu for each access level code. Each level unlocks the functionality of the lower level if the function is enabled POS "13.10" pag. 55.

(POS. 13.10) Restricted access level [Restr.access=ON/OFF] AL2 [RSARE]

If Active this command allows you to view only the functions of the access level entered.

Example: RSARE = ON; Known access level L3; only the functions that operate with access level 3 will be displayed and the other functions will not be displayed.

If this command is set to OFF, the functions with the entered access code and the functions with the access code lower than the one just entered will be displayed.




## **IP ADDRESS SETTING (13.11-12-13)**

(POS. 13.11) Device IP address	[XXX.XXX.XXX]	AL3	[DIPAD]
Device IP network edress			
(POS. 13.12) Client IP address	[XXX.XXX.XXX]	AL3	[CIPAD]
Client IP network adress			
(POS. 13.13) Network mask	[XXX.XXX.XXX]	AL3	[NETMS]


Network mask.

Caution: Changes to the functions of the points 13.11-13.12-13.13 are enabled after the drive device restart(see function POS"12.1" pag. 53).



(POS. 13.14) Coefficient KT	[KF=X.XXXXX]	AL3	[CFFKT]
Gain correction coefficient (calculated automatically).			
(POS. 13.15) Coefficient KS	[KS=X.XXXXX]	AL3	[CFFKS]
Correction coefficient constant instrumental.			
(POS. 13.16) Coefficient KR	[KR=X.XXXXX]	AL5	[CFFKR]
Correction coefficient constant instrumental.			

## **DIGITAL ANALOG CONVERTER (Correction Parameters)**



The diagram shows how the DAC4-20mA parameters are setup. The DAC1 value corresponds to 4 mA corresponding to a zero flow rate, while the value of 20mA corresponds to a 100% of the flow rate.

2 5/10			
(POS. 13.17) Cal. DAC 4mA u.an .1	[DAC1 4mA =XXXXX]	AL5	[C1CP1]
DAC1 out 4mA calibration point. (current output	1 calibration point 1)		
(POS. 13.18) Cal. DAC 20mA u.an .1	[DAC1 20mA=XXXXX]	AL5	[C1CP2]
DAC1 out 20mA calibration point. (current output	t 2 calibration point 1)		
(POS. 13.19) Analog input 1 start scale cal.	[AIN1 SS= $\pm xxxxx$ ]	AL5	[A1CP1]
Analog Input Scale Start Calculation 1. Range of	f settable values are from 0 to 3276	7.	
(POS. 13.20) Analog input 1 full scale cal.	[AIN1 FS= $\pm xxxxx$ ]	AL5	[A1CP2]
Final of analysis and amount adjusted to Danier	f#- -   f 0 t- 00	707	

End of scale analogue input calculation 1. Range of settable values are from 0 to 32767.







(POS. 13.21) Analog input 2 start scale cal. [AIN2 SS=  $\pm xxxxx$ ] AL5 [A2CP1]

Analog input 2 start scale calculation. Settable value range is from 0 to 32767.

(POS. 13.22) Analog input 2 full scale cal. [AIN2 FS=  $\pm xxxxx$ ] AL5 [A2CP2]

End of scale analogue input calculation 2. Range of settable values are from 0 to 32767.

(POS. 13.23) System stand-by mode activation [Stand-by] AL3 [SSTBY]

Enable the converter standby state. It is enabled by selecting rechargeable battery in hw config.

(POS. 13.24) Firmware update [FW update] AL4 [FWUPD]

Enable firmware update. The firmware can be upload to the SD card (name.file).

MCP interface is activated by the command FWUPD = name.file


## **MENU 13 - SYSTEM: ONLY MCP FUNCTIONS**

Unique Identity KEY	[MCP ONLY]	AL0	[UIKEY]
	[MCP ONLY]	ALU	[OIKE1]
Device Unique Identity key.			
Hardware set.	[MCP ONLY]	AL0	[HWSET]
Device hardware configuration.			
Device hardware code	[MCP ONLY]	AL0	[HWCOD]
Device hardware code.			
Firmware CRC-32 value	[MCP ONLY]	AL6	[FWCRC]
FirmWare CRC			
ISOCalmaster Reference	[MCP ONLY]	AL6	[ISOCR]
Measure given by system verification with IsocalMASTER			
Calibr. Exec. status Memory	[MCP ONLY]	AL6	[CALXM]
Calibration Execution status Memory. This function checks  ☐ CALXM=1 instrument calibrated correctly	the instrument's inte	rnal calibration status.	
□ CALXM=0 Invalid calibration / Calibration not complete calibration function, MCP CALIC command).	d (invalid calibration	(if the function is zero,	start the
RTC Real time clock	[MCP ONLY]	AL2	
		ALE	[RTCAC]
This function is used for correcting the internal clock. To set button $^{\textcircled{9}}$ .	t the time of the instr		
	t the time of the instruction the time of the instruction of the time of time of time of t		
button .		ument with the MCP p	rogram, press the
button .  Function code Selection		ument with the MCP p	rogram, press the
button .  Function code Selection  Select the function code.	[MCP ONLY]	ument with the MCP p	rogram, press the
button .  Function code Selection  Select the function code.  Function Enable State Selection	[MCP ONLY]	ument with the MCP p	rogram, press the



Quick Start FuNction Selection	[MCP ONLY]	AL6	[QSFNS]
Select function for quick start menu.			
Quick Start All Functions Selection	[MCP ONLY]	AL6	[QSAFS]
Select ALL function converter for quick start menu.			
Quick start function status List	[MCP ONLY]	AL6	[QSLST]
List quick start group functions.			
Function enable status List	[MCP ONLY]	AL6	[FSLST]
List enable status of functions			
Analog input 1 Start Scale Cal.	[MCP ONLY]	AL6	[A1SSC]
Calibration of the analog input 1 start scale.			
Analog input 1 Full Scale Cal.	[MCP ONLY]	AL6	[A1FSC]
End of scale analogue input calibration 1.			
Analog input 2 Start Scale Cal.	[MCP ONLY]	AL6	[A2SSC]
Calibration of the analog input 2 start scale.			
Analog input 2 Full Scale Cal.	[MCP ONLY]	AL6	[A2FSC]
End of scale analogue input calibration 2.			
Access CODE	[MCP ONLY]	AL0	[ACODE]

Entry of access code through MCP console. Example of adding functions to the Quick start menu via MCP.







LINK Terminate	[MCP ONLY]	AL0	[LTERM]
Terminate the PPP data link			
MCPI session QUIT	[MCP ONLY]	AL0	[MQUIT]
Quit the MCPI connection			
Functions LIST	[MCP ONLY]	AL0	[FLIST]
View list of all available converter functions.			
Functions LISt Compact	[MCP ONLY]	AL0	[FLISC]
View compact list of all available converter functions.			
Functions Menu SELection	[MCP ONLY]	AL0	[FMSEL]
Select menu for functions list			
Configuration list	[MCP ONLY]	AL0	[CFLST]
Configuration parameter list. The list with the status / values	s of the converter para	ameter.	
Hidden functions list	[MCP ONLY]	AL0	[HFLST]
Hidden functions list			
Volume Totalizer Total Positive Set	[MCP ONLY]	AL4	[VTTPS]
Set the value of the total positive totalizer T +.			
Volume Totalizer Partial Positive Set	[MCP ONLY]	AL4	[VTPPS]

Set the value of the positive partial totalizer P +.



Volume Totalizer Total Negative Set	[MCP ONLY]	AL4	[VTTNS]
Set the value of the total negative totalizer T			
Volume Totalizer Partial Negative Set	[MCP ONLY]	AL4	[VTPNS]
Set the value of the negative partial totalizer P			
Volume Total Positive Overflow Set	[MCP ONLY]	AL4	[VTPOS]
Set overflow values for total positive totalisers T +.			
Volume Partial Positive Overflow Set	[MCP ONLY]	AL4	[VPPOS]
Sets the overflow values for P + positive partial totalizers.			
Volume Total Negative Overflow Set	[MCP ONLY]	AL4	[VTNOS]
Set overflow values for total negative totalisers T			
Volume Partial Negative Overflow Set	[MCP ONLY]	AL4	[VPNOS]
Set overflow values for negative partial totalizers T-			
CPU MaX.recorded temperature	[MCP ONLY]	AL6	[CPUMX]
Maximum CPU temperature recorded.			
CPU MiN.recorded temperature	[MCP ONLY]	AL6	[CPUMN]
Minimum recorded CPU temperature.			
Calibration GAin Register 0	[MCP ONLY]	AL6	[CGAR0]
Calibration gain register 0			
Calibration GAin Register 1	[MCP ONLY]	AL6	[CGAR1]
Calibration gain register 1			
Calibration gain register C	[MCP ONLY]	AL6	[CGARC]
Calibration gain register C			





# MENU 14 - FILE (ONLY MCP)

(POS. 14.1) File Transfer ABoRt	[MCP ONLY]	AL2	[FTABR]
Abort the current File Transfer			
(POS. 14.2) File Transfer STAte	[MCP ONLY]	AL0	[FTSTA]
Show file transfer status			
(POS. 14.3) Read Last EVenTs	[MCP ONLY]	AL2	[RLEVT]
Read the latest system events			
(POS. 14.4) Read All EVenTs	[MCP ONLY]	AL2	[RAEVT]
Read all current system events.			
(POS. 14.5) Read Last Logged DaTa	[MCP ONLY]	AL2	[RLLDT]
Read the latest logged data.			
(POS. 14.6) Read All Logged DaTa	[MCP ONLY]	AL2	[RALDT]
Read all current logged data.			
(POS. 14.7) Read Last Sensor Verify Data	[MCP ONLY]	AL2	[RLSVD]
Read the latest sensor ver. data.			
(POS. 14.8) Read All Sensor Verify Data	[MCP ONLY]	AL2	[RASVD]
Read all sensor verify data.			
(POS. 14.9) File SEND	[MCP ONLY]	AL2	[FSEND]
Set file name for read operation.			
(POS. 14.10) File ReCeiVE	[MCP ONLY]	AL5	[FRCVE]
Set file name for write operation.			
(POS. 14.11) File ReCeive APpend mode	[MCP ONLY]	AL2	[FRCAP]
Set file name for write-append.			
(POS. 14.12) File OFFSet position	[MCP ONLY]	AL2	[FOFFS]
Set file offset position.			
(POS. 14.13) ConFiGuration file WRite	[MCP ONLY]	AL2	[CFGWR]
Save the configuration to a file			
(POS. 14.14) ConFiGuration file ReaD	[MCP ONLY]	AL2	[CFGRD]
Read the configuration from file.			
(POS. 14.15) FuNCtion list file WRite	[MCP ONLY]	AL2	[FNCWR]
Save the functions list to file.			
(POS. 14.16) Function Enable Status WRite	[MCP ONLY]	AL6	[FESWR]
Save function enable status to file			



(POS. 14.17) Quick Start function Status WRite	[MCP ONLY]	AL6	[QSSWR]
--	------------	-----	---------

Save quick start function enable.

# **MENU 15 - PROCESS DATA (ONLY MCP)**

(POS. 15.1) OUTput 1 Set	[MCP ONLY]	AL0		[OUT1S]
Set value for digital output 1.				
(POS. 15.2) OUTput 2 Set	[MCP ONLY]	AL0		[OUT2S]
Set value for digital output 2.				
(POS. 15.3) OUTput 3 Set	[MCP ONLY]	AL0		[OUT3S]
Set value for digital output 3.				
(POS. 15.4) OUTput 4 Set	[MCP ONLY]	AL0		[OUT4S]
Set value for digital output 4.				
(POS. 15.5) Digital INput 1 Status	[MCP ONLY]	AL0		[DIN1S]
Digital input 1 status read.				
(POS. 15.6) Digital INput 2 Status	[MCP ONLY]	AL0		[DIN2S]
Digital input 2 status read.				
(POS. 15.7) Digital INput 3 Status	[MCP ONLY]	AL0		[DIN3S]
Digital input 3 status read.				
(POS. 15.8) Flow Rate Full Scale in chosen Units	[MCP ONLY]	AL0		[FRFSU]
Flow Rate Full Scale in chosen Units.				
(POS. 15.9) Flow Rate Value PerCentage	[MCP ONLY]	AL0		[FRVPC]
Flow Rate Value PerCentage.				
(POS. 15.10) KL TeST	[MCP ONLY]	AL0		[KLTST]
KL test.				
(POS. 15.11) Flow Rate Value Percentage without cut-off	[MCP ONLY]	AL0		[FRVPX]
Flow Rate Value Percentage without cut-off.				
(POS. 15.12) Flow Rate Value Binary without cut-off	[MCP ONLY]		AL0	[FRVBX]
Flow Rate Value Binary without cut-off.				
(POS. 15.13) Flow Rate Value Technical Unit	[MCP ONLY]		AL0	[FRVTU]
Flow Rate Value Technical Unit.				
(POS. 15.14) Volume Totalizer Total Positive Value	[MCP ONLY]	AL0		[VTTPV]
Volume Totalizer Total Positive Value.				
(POS. 15.15) Analog input 1 Value Technical Unit	[MCP ONLY]	ALO		[A2VTU]
Analog input 1 value in technical units				







(POS. 15.16) Analog input 2 Value Technical Unit	[MCP ONLY]	AL	.0	[VTTPV]
Analog input 2 value in technical units				
(POS. 15.17) Volume Totalizer Partial Positive Value	[MCP ONLY]	AL0		[VTPPV]
Volume Totalizer Partial Positive Value.	-			
(POS. 15.18) Volume Totalizer Total Negative Value	[MCP ONLY]	AL0		[VTTNV]
Volume Totalizer Total Negative Value.				
(POS. 15.19) Volume Totalizer Partial Negative Value	[MCP ONLY]	AL0		[VTPNV]
Volume Totalizer Partial Negative Value.				
(POS. 15.20) Volume Totalizer Total Positive Overflow	[MCP ONLY	]	AL0	[VTTPO]
Volume Totalizer Total Positive Overflow.				
(POS. 15.21) Volume Totalizer Partial Positive Overflow	[MCP ONLY	]	AL0	[VTPPO]
Volume Totalizer Partial Positive Overflow.				
(POS. 15.23) Volume Totalizer Total Negative Overflows	[MCP ONLY	]	AL0	[VTTNO]
Volume Totalizer Total Negative Overflow.				
(POS. 15.24) Volume Totalizer Partial Negative Overflow	[MCP ONLY	]	AL0	[VTPNO]
Volume Totalizer Partial Negative Overflow.				
(POS. 15.25) Volume Totalizers ALL	[MCP ONLY	1	AL0	[VTALL]
Volume Totalizers all.				
(POS. 15.26) Board TeMPeratures	[MCP ONLY]	AL0		[BTMPS]
Board Temperatures.				
(POS. 15.27) CPU TemPerature	[MCP ONLY]	AL0		[CPUTP]
CPU Temperature.				
(POS. 15.28) Sensor CoiLs TemPerature	[MCP ON	LY]	AL0	[SCLTP]
Sensor coils temperature.				
(POS. 15.29) LiQuid VELocity	[MCP ONI	LY]	AL0	[LQVEL]
Liquid velocity.				
(POS. 15.30) AVeraGe process data Samples Number	[MCP ONI	.Y]	AL0	[AVGSN]
Average process data samples number				

Average process data samples number.



(POS. 15.31) ALARM status	[MCP ONLY]	AL0	[ALARM]
Alarm status.			
(POS. 15.32) Sensor TeSt Result Code	[MCP ONLY]	AL0	[STSRC]
Sensor Test Result Code			
(POS. 15.33) Main PoWeR Status	[MCP ONLY]	AL0	[MPWRS]
Main Power Status			
(POS. 15.34) equivalent INput RESistance	[MCP ONLY]	AL0	[INRES]
Input resistance			
(POS. 15.35) INput VoLtageS	[MCP ONLY]	AL0	[INVLS]
Input voltages			
(POS. 15.36) Sensor TaBLe Version	[MCP ONLY]	AL0	[STBLV]
Sensor table version			
(POS. 15.37) MoDeM STatus	[MCP ONLY]	AL0	[MDMST]
Operating status of the modem			
(POS. 15.38) SEQuence NumBer	[MCP ONLY]	AL0	[SEQNB]

Sequence number. The SEQNB command allows you to specify a sequence number to be used when querying the meter (additional verification procedure). The same number that is set with SEQNB = number is retransmitted as a response by the converter. This function, together with the process commands used to read the variables (capacity, volumes, etc.) allows to keep synchronized the received values with the requests made. In this way it is possible to verify the temporal sequence with which the messages are received by the meter.

Example:

Request: SEQNB=1;FRVPC? Request: 1;%,12.345678 Request: SEQNB=2;FRVPC? Request: 2;%,11.456778 Request: SEQNB=3;FRVPC? Request: 3;%,10.983228 Request: SEQNB=4;FRVPC?

..

<= Sequence 4 is missing, error

..

Request: SEQNB=5;FRVPC? Return: 5;%,10.992783

The example shows how SEQNB can help identify exactly what message was lost. In this case the requests are all the same (apart from the SEQNB number), but with different requests, SEQNB can be a verification tool.






## **METER DATA**

This function allows the import of data from one converter to another up to level 4 included. The hardware configurations and the corresponding calibration values are not restored. The "data import" procedure can be performed one time only, since the directory, according to the board's SERIAL NUMBER, will be renamed.

OPERATING PROCEDURE TO CHANGE THE CONVERTER BOARD





Remove the 4 screws (see "power supply converter" pag. 20 ) to be able to remove the battery case. Attention to the internal wiring of the instrument.





Remove the 2 screws (see "MV255 CONSTRUCTION" pag. 17) to be able to remove the battery case cover. Attention to the internal wiring of the instrument











Remove the 4 screws (see "MV255 CONSTRUCTION" pag. 17) to remove the MV255 card. Attention to the board wiring.





Remove the 4 screws (see "MV255 CONSTRUCTION" pag. 17) to remove the MV255 card. Attention to the board wiring. Remove the SD card and insert it into the new card.



Once the card is assembled to the converter, perform the following procedures:

- □ Connect the internal wiring to the board without directly connecting the batteries (see diagrams "power supply converter" pag. 20 ).
- ☐ Assemble the MV housing cover (see "torques" pag. 16).
- ☐ Assemble the battery case cover (see "torques" pag. 16).
- ☐ Connect the batteries of the housing to the cable / wiring to the board.
- ☐ Assemble the battery case with the 4 screws removed (see "torques" pag. 16).
- □ Correctly assembled the converter start the function ("11.8" pag. 55) to restore data.





## **B.I.V. (BUILT-IN VERIFICATOR)**

BIV, abbreviation for Built In Verificator, is available as option for MV255 converters and must be enabled by the manufacturer. It is also necessary that the SD card is activated to store saved data. The analysis of collected data performed by a dedicated IsoBIV software running on another device (PC).

The simplicity of test procedures minimize the risk of handling errors; maximum safety and reliability thanks to the traceable factory calibration and internal references complement the safety by design principle with minimal failure rates IsoBIV allows to create and print a report as validation of device functionality/measure error.

## Operation and Conditions of Use.

The system is based on periodic measurements performed every hour or using a manual command (MCP command = SVERC). The sensor parameters are measured and compared with previously measured and stored reference values. Each time the system performs a series of measurements on the sensor and records them in a file called "STESTLOG. CSV", which resides in the main directory of the SD memory of the converter.

The sensor test can also be carried out without the active BIV system, but in this case only the presence of isolation losses and the overall good functioning of the sensor such the coil resistance, the excitation current and the rising times of the current within the generic limits that guarantee operation. Instead if BIV is active, the measurements are deeper and the measured values are tested by comparing them with a set of characteristic sensor parameters measured at the time of installation.

### Saving Reference Values (Characteristic Parameters)

After sensor installation, the parameters that will be used as reference for the BIV system and the IsoBIV data analysis software must to be measured.

The characteristic values of the coil circuits are saved in the converter memory at the factory before to ship the instrument. For the reference measure of the electrodes circuits, there is a specific function that perform the measures of voltage and resistance at the installation site. This function is managed ONLY by the IsoBIV program, which through a simple wizard will set the converter to perform the measures in the specific measurement point where the meter is installed.

To activate BIV, these functions must be verified:

□ **[ASVFE=1]:** It enable the sensor's automatic test every hour. The ASVFE function in Menu 1 with access level 3 can be also activated using the instrument's display.


This feature can be enabled even if the SD card is not installed and if the BIV function is not active; in such a case the sensor file is NOT created and any alarms will be generated either if the data deviation from the reference data is outside the sensor's limits. Practically, in the absence of the necessary hardware permissions, this function is useful to test the insulation of the coils.



### Opening and reading manually the files STESTLOG.CSV

The list below describes the steps for saving and reading STESTLOG.CSV file.

- □ Start the MPC program for opening the converter menu interface.
- Follow these steps:







☐ Reading and meaning of the STESTLOG.CSV file



(#): the units of measurement are recorded only if the specific function of the DATA LOGGER is active. Otherwise the field

(\*): the temperature values can be expressed in degrees F or C, depending on the configuration of the converter.

⊢	000.0+ 0.000 0+ 0.000 0+ 0.000 0+ 0.000 0+ 0.000 0+	Common mode noise at low frequency		
တ		The unit of voltage (V) (#)		
22	0.0	Resistance measured between E2 and the common		
Ø		The unit of resistance (ohm) (#)		
۵	0.0	Resistance measured between E1 and the common		
0		The unit of resistance (ohm) (#)		
z	00000+ 00000+ 00000+ 00000+ 00000+ 00000+ 00000+	Common mode voltage (E1 + E2) / 2		
Σ		The unit of voltage (V) (#)		
٦	00000+ 00000+ 00000+ 00000+ 00000+ 00000+ 00000+	Differential voltage E1-E2		
ᅩ		The unit of voltage E2 (V) (#)		
ſ	000.0+ 0.000 0+ 0.000 0+ 0.000 0+ 0.000 0+ 0.000 0+ 0.000 0+	Reference voltage electrode E2		
_		The unit of voltage E1 (V) (#)		
ェ	000.0+ 0.000 0+ 0.000 0+ 0.000 0+ 0.000 0+ 0.000 0+	Voltage measured on the electrode E1		
ග		The unit of voltage CPU (V) (#)		
ட	28 28 28 28 28 28 28	CPU temperature		
Ш		The temperature unit (degrees F or C) (#) (*)		
Ω	000000	Error code in hexadecimal format (0 = no error)		
ပ	ORA 00:00:00 00:00:00 00:00:00 00:00:00 00:00:	hours		
В	DATA dd/mm/yy dd/mm/yy dd/mm/yy dd/mm/yy	Date		
A	0 + 8 8 8 9	Registration number		



Ą	hex	Raw checksum			
A	0.000	Rise time current phase B			
A		Unit of measure of time (ms) (#)			
¥	0.000 0.000 0.000 0.000 0.000 0.000	Rise time current phase A			
AM		Unit of measure of time (ms) (#)			
甘	0.000	The coil leakage current (insulation fault)			
¥		The unit of current (mA) (#)			
3	0.000 0.000 0.000 0.000 0.000 0.000	Temperature of the sensor coils			
₹		The temperature unit (degrees F or C) (#) (*)			
¥	0.000 0.000 0.000 0.000 0.000 0.000	Measurement of the sensor coil resistance			
AG		The unit of resistance (ohm) (#)			
Ą	0.000 0.000 0.000 0.000 0.000 0.000	Excitation current of the coils			
믬		The unit of current (mA) (#)			
Ф	+0.000 +0.000 +0.000 +0.000 +0.000 +0.000 +0.000	Negative supply voltage analog circuits			
AC		The unit of voltage (V) (#)			
AB	000.00	Analog circuitry positive supply voltage			
₹		The unit of voltage (V) (#)			
Z	000.00	Mode ADC noise high frequency differential			
>		The unit of voltage (mV) (#)			
×	00000 00000 00000 00000 00000 00000 0000	Mode ADC noise at low frequency differential			
≥		The unit of voltage (mV) (#)			
>	00000+ 00000+ 00000+ 00000+ 00000+ 00000+	Differential mode noise at low frequency			
D.	0 (0x0000000000000000000000000000000000	Presence of alarm and descriptive hexadecimal code			





#### Standard and internal check to the instrument limits

The measured data are compared with the reference values previously stored. The variation of different variable measured, shall be within the following range:


- ☐ Coil temperature (using resistance reading): within limits compatible with the lining material
- ☐ Current up times: change% detected resistance coils + 10% (tolerance range)
- ☐ Resistance between electrodes and common: between 0.3 and 3.0 times the reference early strength
- ☐ Leakage current (insulation test): less than 0.1 mA

If the values deviate beyond these limits it is generated and displayed a coded alarm.

The alarm remains active and visible on the display until next test (max. 1 hour).

## MCS SOFTWARE

Meter Checking System (MCS) Is a modular system that provides diagnostic activities. The system is made up of multiple components: the enabled functions depend on the connected instrument.



#### MCS for MV255

When a MV255 is connected to MCS is possible to use all the system MCS sections.

For the section BIV analyzer (purple section) it's necessary to have selected the BIV option in order phase.

For the section IsocalMaster (green section) It's necessary to connect an IsocalMaster device.

See the MCS software manual for more information.



## **ALARM MESSAGES (CAUSES AND ACTIONS TO BE TAKEN)**

Alarm coding table with added bit-code values that appear on the data logger. The codes can be added when there are several alarms simultaneously. The codes are in HEX format, so for calculations on sums (which are arithmetic ORs) you need to use HEX mathematics and not decimal.a. Example 1: 10H (16 decimal) + 20H (32 decimal) = 30H (48 decimal).

b. Example 2: 10H (16 decimal) + 4H (4 decimal) = 14H (20 decimal)

CODE	BITCODE DATA LOGGER (HEXADECIMAL)	ALARM DESCRIPTION	CAUSE/SOLUTIONS
00	0000000000000001	PCB is not inizializated	Contact the service
01	000000000000000000002	F-RAM error	Try to restart. If the error persists, please contact the service
02	0000000000000004	SD-card error	Try to restart. f the error persists, contact the service
03	000000000000000	The SD-card isalmost full	Plan to replace the SD-card as soon as possible
04	0000000000000010	The SD-card is full	Replace the SD-card
05	000000000000000000000000000000000000000	Power Primary absent	This alarm condition can be configured by the user. Evaluate whether this condition is normal or unexpected
06	0000000000000040	Communication error between s.	Try to restart. If the error persists Contact the service
07	000000000000000000000000000000000000000	Low baterries level	Replace the batteries or charge the batteries if they are rechargeable.
08	000000000000100	ISOCALMASTER connected	ISOCALMASTER module inserted and correctly recognized
19	00000000000800000	Internal voltage error	Contact the service
22	0000000000400000	Excitation error	Sensor not connected correctly, broken or incorrect wiring, faulty connections or incorrect sensor piloting parameters.
23	00000000000000000	Signal error	Critical measurement conditions, lack of valid earth connection, presence of persistent electrical disturbances or incorrect or interrupted wiring / connections with the sensor.
24	000000001000000	Empty tube	The sensor is empty. Check the presence of liquid in the connected piping, check the correct setting of the maximum allowable resistance on the electrodes.
25	0000000002000000	Max flow alarm +	Check the process conditions and the MAX + alarm threshold set
26	0000000004000000	Max flow alarm -	Check the process conditions and the MAX - alarm threshold set
27	0000000008000000	Min flow alarm +	Check the process conditions and the set MIN + alarm threshold
28	000000010000000	Min flow alarm -	Check the process conditions and the set MIN - alarm threshold
29	0000000020000000	Flow rate > F.sclae +	Check the process conditions and the full scale value set
30	00000004000000	Flow rate < F.sclae +	Check the process conditions and the full scale value set







31	000000080000000	Pulse output 1 out of range	Check process conditions and set values for pulse unit 1 and pulse duration 1
32	0000000100000000	Pulse output 2 out of range	Check process conditions and set values for pulse unit 2 and pulse duration 2
33	0000000200000000	Calibration error	Make sure that the sensor is connected correctly and that the sensor type matches the one set. If the error persists, contact the service
34	0000000400000000	Sensor error	The sensor test has failed. Examine the code reported in the event logger or diagnostic values page to determine possible causes.  ATTENTION: the error condition persists until the next test is performed or until the instrument is restarted.
35	0000000800000000	Configuration login failed	An attempt was made to access the configuration parameters with an incorrect password. This alarm condition can be configured by the user.
36	0000001000000000	Configuration access detected	Access to configuration parameters was detected. This could be a legitimate or unexpected operation. The alarm condition can be configured by the user.
37	0000002000000000	System violation	A system integrity violation was detected. This alarm is detected by means of a switch connected to a digital input of the instrument specifically configured for this use
38	0000004000000000	Flooding	A system flood condition has been detected. This alarm is detected by a switch connected to a digital input of the instrument specially configured for this use
39	000000800000000	Analog input 1 error	The signal or sensor connected to the optional analog input 1 are incorrect or not configured correctly. Check the relative wiring and that the sensor type is correct / functioning.
40	0000010000000000	Analog input 1 out of range	The signal deriving from the sensor connected to the optional analogue input 1 is too large for the configured measurement scale. Review the configuration parameters and check that the sensor is connected correctly.
41	0000020000000000	Misura ingresso analogico 1 maggiore soglia MAX	Check the process conditions and the threshold set as the maximum signal alarm for the optional analog input 1
42	0000040000000000	Misura ingresso analogico 1 minore soglia MIN	Check the process conditions and the threshold set as a minimum signal alarm for the optional analog input 1
43	0000080000000000	Analog input 2 error	The signal or sensor connected to the optional analogue input 2 is incorrect or not configured correctly. Check the relative wiring and that the sensor type is correct / functioning.
44	0000100000000000	Analog input 2 out of range	The signal deriving from the sensor connected to the optional analogue input 2 is too large for the configured measurement scale. Review the configuration parameters and check that the sensor is connected correctly.



45	0000200000000000	Misura ingresso analogico 2 maggiore soglia MAX	Check the process conditions and the threshold set as the maximum signal alarm for the optional analog input 2
46	0000400000000000	Misura ingresso analogico 2 minore soglia MIN	Check the process conditions and the threshold set as a minimum signal alarm for the optional analog input 2
47	000080000000000	System protection error	The system has detected a protection error related to the MID parameters.Contact the service
48	0001000000000000	System restarted	Evaluate whether the reboot was expected.  Otherwise consult the event logger to determine the causes.
49	00020000000000000	Invalid time / date	Set the time and date
50	0004000000000000	CPU frequency error	Contact the service
51	0008000000000000	Temperature out of range for battery charge	The rechargeable battery cannot be recharged because the detected temperature is outside the allowed limits. Check the operating conditions.
52	0010000000000000	Battery voltage rechargeable too high	The rechargeable battery voltage is higher than the allowable limits. Turn off the appliance immediately, disconnect the battery and contact the service.
53	0020000000000000	Charge current too high	The charging current of the rechargeable battery is beyond the allowable limits. Turn off the device immediately, disconnect the battery and contact the service.
54	0040000000000000	Secondary voltage supply error	The power supply voltage is insufficient (probable case with solar panel in poor lighting conditions). If, on the other hand, the power supply voltage is within the expected limits and the alarm persists, contact the service.
55	0080000000000000	Configuration login failed	An attempt was made to access the configuration parameters with an incorrect password. This alarm condition can be configured by the user.
56	01000000000000000	Configuration access detected	Access to configuration parameters was detected. This could be a legitimate or unexpected operation. The alarm condition can be configured by the user.





## **ERROR CODE TEST SYSTEM OF SENSOR**

The codes are in hexadecimal format, the meaning is given for each bit. There are several possible error simultaneous combinations (more bits active) then that will give the combined numerical codes.

CODE	ANOMALIES DESCRIPTION	ACTION TO TAKE	
0000	NO ERROR		
0001	SENSOR TEST INSULATION: Generator power too low.	Contact the service	
0002	SENSOR TEST INSULATION: Generator power too high.		
0004	SENSOR TEST INSULATION: Phase 1 generator voltage too low.		
8000	SENSOR TEST INSULATION: Phase 1 generator voltage too high.		
0010	SENSOR TEST INSULATION: Phase 1 terminal voltage coils 1 too low.		
0020	SENSOR TEST INSULATION: Phase 1 terminal voltage coils 2 too low.		
0040	SENSOR TEST INSULATION: Phase 2 generator voltage too low.		
0800	SENSOR TEST INSULATION: Phase 2 generator voltage too high.		
0100	SENSOR TEST INSULATION: Phase 2 terminal voltage coils 1 too low.		
0200	SENSOR TEST INSULATION: Phase 2 terminal voltage coils 2 too low.		
0400	SENSOR TEST INSULATION: Insulation loss, leakage current out of tolerance.		
0800	TEST TEMPERATURE (RESISTANCE) COILS:  Temperature (resistance) out of tolerance.  To verify:		
1000	TEST TIME GETTING ON CURRENT PHASE (A):  Value out of tolerance.  - wiring between converter s - conditions of use,		
2000	TEST TIME GETTING ON CURRENT PHASE (B): Value out of tolerance.	- set parameters.  If the problem persists, contact the service	
4000	TEST RESISTANCE INPUTS ELECTRODES: Input value 1 out of tolerance.		
8000	TEST RESISTANCE INPUTS ELECTRODES: Input value 1 out of tolerance		
10000	Excitation error during the test	The sensor test failed because an excitation error was present. Check the sensor wiring and the parameters set, in particular check that the type of sensor is set correctly.	
20000	Invalid reference values	The reference values used to check the measurements detected on the sensor are not valid. Perform the procedure for storing reference values correctly.	
40000	Empty tube	The tube is empty and therefore it is not possible to check the values measured on the electrodes.  Check the installation conditions and the parameters related to the recognition of the empty pipe condition (maximum resistance threshold on the electrodes).	







At the end of its lifetime, this product shall be disposed of in full compliance with the environmental regulations of the state in which it is located.



# **MANUAL REVIEWS**

REVIEW	DATE	DESCRIPTION
255_EN_IT_R0_1.00.0	13/02/2019	First edition
255_EN_IT_R1_1.00.0	04/06/2019	Added information on converter delivery conditions
255_EN_IT_R2_1.00.0	26/09/2019	ADD note battery specification battery option B-C
255_EN_IT_R3_1.02.0	24/06/2020	Software update, Netw. frequency function and new display pages added
MAN_MV255_IT_EN_R04_1.05.XXXX	21/01/2022	Firmware update, graphics update, MODBUS section moved to a separate manual
MAN_MV255_IT_EN_R05_1.05.XXXX	19/05/2022	Corrections on Alarms menu
MAN_MV255_IT_EN_R06_1.05.XXXX	04/08/2022	Changes on alarms table
MAN_MV255_IT_EN_R07_1.05.XXXX	20/09/2022	Correct drawing and description added in the "output connections" section
MAN_MV255_IT_EN_R08_1.05.XXXX	18/10/2022	Corrections to download datalogger table
MAN_MV255_IT_EN_R09_1.05.XXXX	18/01/2023	Corrections on battery power supply section and on descriptions of some functions
MAN_MV255_IT_EN_R10_1.06.XXXX	16/02/2023	Update of visualization pages
MAN_MV255_IT_EN_R11_1.06.XXXX	15/06/2023	Adedd measurement tollerance and note on galvanic insulation
MAN_MV255_IT_EN_R12_1.06.XXXX	24/10/2023	Added information about OUT 4_20 mA and about turning the instrument on and off
MAN_MV255_IT_EN_R13_1.06.XXXX	07/11/2023	Added notes about external power supply
MAN_MV255_IT_EN_R14_1.06.XXXX	14/12/2023	Added notes about download data
MAN_MV255_IT_EN_R15_1.06.XXXX	29/07/2024	Added MCS section
MAN_MV255_IT_EN_R16_1.06.XXXX	16/06/2025	Updated section on Modbus and use of 4-20 mA output









# ISOIL INDUSTRIA S.p.A.

HEAD OFFICE	SERVICE
Via Fratelli Gracchi, 27	service@isoil.it
20092 Cinisello Balsamo (MI)	
Tel +39 02 66027.1	
sales@isoil.it	

If you want to find the complete list of our distributors access at the following link: http://www.isoil.it/en



Due to the constant technical development and improvement of its products, the manufacturer reserves the right to make changes and/or modify the information contained in this document without notice.

